

Lay the frame pad over the trampoline so that the springs and the steel frame are covered (A). Please ensure that the frame pad covers all metal parts.

Attach the straps that you find at the bottom of the edge cushion to the triangle of the jumping mat (B) and attach the strap with the hook also to it (see figure C).



B



C

