

INSTALLATION



1. Clean the area around your device's webcam carefully with the cleaning cloth included.



2. Peel off the sticker.



3. Install the webcam cover on your device. (Be careful not to cover the indicator light and sensor.)



4. Press the webcam firmly in place and hold for about 12 seconds. It makes 3M Adhesive more durable.