



MAGNETIC POWERBANK


Gebruikershandleiding

- P.1 Nederlands - Handleiding
- P.4 English - User Manual
- P.6 Legal Information



Bedankt dat u voor Silicon heeft gekozen!

De Silicon powerbank is een hoogwaardige en betrouwbare draagbare magnetische oplader, ontworpen om je apparaten onderweg opgeladen en klaar voor gebruik te houden. Met een krachtige capaciteit is het perfect voor het opladen van smartphones, tablets en andere USB-apparaten. De powerbank beschikt over geavanceerde technologie om efficiënt opladen en langdurige prestaties te verzekeren, waardoor je verbonden en productief blijft tijdens reizen of lange dagen weg van stopcontacten. De Silicon powerbank is duurzaam, compact en licht, waardoor het de ideale reisgenoot is voor elke moderne technologiegebruiker. Namens het Silicon-team hopen wij dat u er veel plezier mee zult hebben. Voor verdere hulp kunt u contact met ons opnemen: klantenservice@silcon.nl



Uitleg product:

- 1 Aan/UIT knop: Groen symbool geeft 20W snel laden aan.
- 2 Ingang/UITgang (Type-C PD)
- 3 Lightning Ingang (Voor Apple oplaadkabel)
- 4 LED Display voor indicatie batterij
- 5 Magnetische oppervlakte

Specificaties:

Ingang: 5V=2A (Lightning)
 Ingang: 5V=3A 9V=2A 12V=1.5A (Type-c interface PD) Uitgang: 5V/2A 9V/2.22A 12V/1.5A (Type-c interface PD)
 Uitgang: 5W /7.5W/15W (Draadloze oplader)
 Batterij: 10000 mAh
 Gebruiktemperatuur: 0 °C - 40 °C
 Productgrootte: (L) 104 × (W) 68 × (H) 15 (mm)
 Gewicht van het product: =145g

01-NL

02-NL

03-NL

Gelieve de volgende stappen te volgen om de Silicon Powerbank te gebruiken:

1. Druk kortstondig op de aan/uit-knop om de powerbank te activeren, op het display zal de huidige lading worden weergegeven.
2. In het geval van de snellaadfunctie, ongeacht of deze in- of uitvoert, wordt een "Lightning"-aanduiding op het scherm weergegeven.
3. Door tweemaal op de aan/uit-knop te drukken, kan de powerbank worden uitgeschakeld.

Om de powerbank op te laden, dient u de volgende procedure te volgen:


Deze powerbank wordt geleverd met een Type-C oplaadkabel. Sluit de meegeleverde kabel aan op een USB-voeding om de powerbank op te laden. Gedurende het oplaadproces zal het percentage op het display knipperen. Wanneer de powerbank volledig is opgeladen, zal het display een constante 100% weergeven. Het volledige oplaadproces neemt gemiddeld een tijdsperiode van ongeveer 4 uur in beslag. Wacht echter tot het display 100% aangeeft.

Let op de volgende instructies:

- Laad het product volledig op bij eerste gebruik.
- Indien zwellen, lekkage, vervorming, onderdempeling in water, of anderszins optreedt, staak gebruik onmiddellijk.
- Vermijd vallen, hoge temperaturen, vochtige omgevingen en sterke magnetische velden.
- Houd buiten bereik van kinderen.
- Laot het product niet achter in een auto onder sterk zonlicht.
- Voorkom vervuiling in de input/output poorten.
- Controleer of de ingangsspanning van het apparaat overeenkomt met de uitgang van de powerbank.
- Om prestatievermindering te voorkomen, dient de powerbank elke 3 maanden volledig te worden opgeladen en ontladen, in geval van langdurige inactiviteit.
- Vermijd demontage, oek, perforatie, kortsluiting, contact met water, blootstelling aan vuur of temperaturen boven 40°.
- Verifieer, voorafgaand aan gebruik, of het voltage van de powerbank overeenstemt met dat van het op te laden apparaat.
- Gebruik de powerbank alleen zoals beschreven in de handleiding. Elk ander gebruik wordt als ongepast beschouwd en kan leiden tot letsel of materiële schade. Silcon is niet verantwoordelijk voor schade of letsel als gevolg van aanrijding of ontzorging gebruik.

Thank you for choosing Silcton!

The Silicon power bank is a high-quality and reliable portable magnetic charger, designed to keep your devices charged and ready to use on the go. With a powerful capacity, it is perfect for charging smartphones, tablets and other USB devices. The power bank features advanced technology to ensure efficient charging and long-lasting performance, keeping you connected and productive during travel or long days away from electrical outlets. The Silicon power bank is durable, compact and lightweight, making it the ideal travel companion for any modern technology user. On behalf of the Silicon team, we hope you will enjoy it. For further assistance, please contact us: customerservice@silcon.nl



Product explanation:

- 1 On/Off button: Green symbol indicates 20W fast charging.
- 2 Input/Output (Type-C PD)
- 3 Lightning Input (For Apple charging cable)
- 4 LED Display for battery indication
- 5 Magnetic surface

Specifications:

Input: 5V=2A (Lightning)
 Input: 5V=3A 9V=2A 12V=1.5A (Type-c interface PD) Output: 5V/2A 9V/2.22A 12V/1.5A (Type-c interface PD)
 Output: 5W /7.5W/15W (Wireless output)
 Battery: 10000mAh
 Operating temperature: 0°C-40°C
 Product size: (L) 104 × (W) 68 × (H) 15 (mm)
 Product weight: =145g

04-EN

Please follow the following steps to use the Silicon Powerbank:

1. Briefly press the power button to activate the power bank. The display will then show what percentage of power is still available.
2. In the case of the fast-charging function, whether it is input or output, a "Lightning" indication will be displayed on the screen.
3. By pressing the power button twice, the power bank can be turned off.

To charge the power bank, follow the following procedure:

This power bank comes with a Type-C charging cable. Connect the supplied cable to a USB power supply to charge the power bank. During the charging process the percentage will flash on the display. When the power bank is fully charged, the display will show a constant 100%. The entire charging process takes an average of approximately 4 hours. However, wait until the display shows 100%.

Please note the following instructions:

- Fully charge the product when using it for the first time.
- If swelling, leakage, deformation, immersion in water, or short circuit occurs, discontinue use immediately.
- Avoid drops, high temperatures, humid environments, and strong magnetic fields.
- Keep out of reach of children.
- Do not leave the product in a car under strong sunlight.
- Prevent contamination in the input/output parts.
- Check whether the input voltage of the device matches the output of the power bank.
- To avoid performance degradation, the power bank should be fully charged and discharged every 3 months, in case of prolonged inactivity.
- Avoid disassembly, pressure, perforation, short circuit, contact with water, exposure to fire or temperatures above 40°.
- Before use, verify that the voltage of the power bank matches that of the device to be charged.
- Only use the power bank as described in the manual. Any other usage is considered inappropriate and may lead to injuries or material damage. Silcton is not responsible for any damage or injury resulting from incorrect or careless usage.

READ BEFORE FIRST USE

To begin, please inspect all components from the packaging and remove any stickers and foil. Proceed to inspect each item to ensure that no damage has been sustained and that no parts are missing. If a component is missing or appears to be damaged, do not use the product. Instead, please reach out to our customer service team at customerservice@silcon.nl for further assistance.

BE AWARE WITH CHILDREN

Plastic Bags and Films: To avoid the potential risk of asphyxiation, it is of utmost importance to keep plastic bags and films out of reach from infants and children. These thin films can adhere to their nose and mouth, obstructing their ability to breathe.

Risk of Strangulation: Cables, cords, and strings entangled further than 18 CM (7 inch) may present a risk to infants and very young children, as they may become entangled while playing. Ensure to properly store the cord to avoid potential incidents.



RECYCLE INFORMATION

Batteries, electrical and electronic equipment (EEE) contain materials, components and substances that can be hazardous to the environment and harmful to human health if waste electrical and electronic equipment (WEEE) is not disposed of correctly. Batteries, electrical and electronic equipment marked with the WEEE logo (as shown below) should not be disposed of with household waste. Contact your municipality's waste management department. They can inform you about the recycling options in your region. Dispose of all packaging materials in an environmentally friendly manner.



WARRANTY

Under the Silicon warranty, this product is guaranteed free from material and manufacturing defects for one year from the date of purchase. This warranty applies to personal use only. In the event of any defects within this period, Silicon reserves the right to repair or replace the product or parts at its sole discretion. This warranty is limited to the original purchaser and requires proof of purchase. The warranty is not transferable and does not apply to negligent use of the product, loss of voltage or amperage, water damage, use contrary to the manual, repairs by non-warranty parties, accident or disaster damage and normal wear and tear. Silicon is not liable for consequential damage or damage due to improper use and reserves the right to change specifications, colors, accessories, materials, and models without notice.

CONFORMITY

Silcton (hereinafter: Inweeth-BV) hereby declares that this product complies with the EMC guidelines.
 2014/53/EU
 EN 50364-2018 EN 303 477 V1.1:2017 EN 301 489-1 V2.2.2:2019 EN 301 486-3 V2.1:2019



WARNING

The contents of this document on presentation is who they currently exist. Inweeth-BV accepts, expressly or tacitly, any warranty for the accuracy and completeness of the contents of this document. Inweeth-BV reserves the right to make changes to this document or to withdraw it completely at any time without notice.

Imported by:

Inweeth BV,
 Torenstraat 35
 1275XZ Huzen
 The Netherlands
 info@silcton.nl

05-EN

06-EN - Legal Information