


... de montage
 doit être défilé. Les lampes ne peuvent pas être remplacées. Cette guirlande
 n'est pas un jouet - tenir hors de portée des enfants. Cet ensemble d'éclairage
 a 3 fonctions : 1. "TIMER" pour allumer pendant 6 heures et éteint pendant 18
 heures, 2. "ON" pour allumé en continu, 3. "OFF" pour éteint en continu.



DE - Nur für den Einsatz im Innenbereich. Das flexible Kabel dieses
 Beleuchtungssets kann nicht ausgetauscht werden, wenn das Kabel
 beschädigt ist, ist das Beleuchtungsset zu beseitigen. Die Lampen können nicht
 ausgetauscht werden. Diese Lichtkette ist kein Kinderspielzeug - Bitte für Kinder
 unzugänglich anbringen. Dieses Beleuchtungsset hat 3 Einstellungen: 1. „ON“
 = Dauerbetrieb, 2. „TIMER“ = automatisch 6 St. an und 18 St. aus, 3. „OFF“
 = dauerhaft aus.



EN - for indoor use only. The external flexible cable or cord of this luminaire
 cannot be replaced, if the cord is damaged, the luminaire shall be destroyed.
 The lamps are not replaceable. This lighting chain is no toy - please keep it
 inaccessible for children. This light set has 3 functions: 1. "ON" for continuously
 switched on; 2. "TIMER" for switching the light on/off automatically (6
 hours on and 18 hours off); 3. "OFF" for continuously switched off.



2 x AA (Not included)

Itemnr.: 231329



8 713619 389955

CBD PO BOX 16
 1738 ZG WAARLAND (NL)

