



**HANDLEIDING - INDUCTIE BESCHERMER  
USER MANUAL - INDUCTION HOB COVER**



## NEDERLANDS

Bedankt voor het aanschaffen van onze KitchyMist inductiebeschermer.

Lees voor gebruik de handleing nauwkeurig door.

Deze instructies bevatten belangrijke veiligheidswaarschuwingen die te allen tijde in acht genomen dienen te worden.

Veel plezier met uw inductie beschermer!

### 1. VEILIGHEIDSINSTRUCTIE

Plaats de Inductie Beschermer **NOOIT** op een heet oppervlak. Wacht na gebruik van de inductieplaat totdat deze is afgekoeld, voordat u de inductie beschermer op de inductieplaat plaatst.

Het is belangrijk dat u de kookplaat **NOOIT** aanzet wanneer de inductieplaat nog door de inductie beschermer bedekt wordt.

**DISCLAIMER:** KitchyMist is in geen enkel geval aansprakelijk voor schade aan de inductiekookplaat door het onjuist gebruik van de inductie beschermer.

### 2. EERSTE KEER IN GEBRUIK

De inductie beschermer dient op kamertemperatuur te komen voordat de beschermer recht trekt. Door verschillende temperaturen kan dit in sommige gevallen wat langer duren.

### 3. VERLENGEN VAN DE LEVENSDUUR

Rol de inductie beschermer op voordat u de kookplaat aan zet. Daarbij is het van belang dat u de inductie beschermer oprolt, en niet opvouwt, want dit kan de print beschadigen. Gebruik de Inductie Beschermer niet als een snijplank, want dit kan de print beschadigen.

### 4. SCHOONMAAKINSTRUCTIES

Maak de kookplaat eerst schoon voordat u de inductie beschermer erop plaatst, om te voorkomen dat de onderzijde van de inductie beschermer smerig wordt.

Om de inductie beschermer schoon te maken, neemt u het af met een schone doek. Hierbij kunt u eventueel afwasmiddel gebruiken. Gebruik geen andere schoonmaakmiddelen.

## ENGLISH

Thank you for purchasing the KitchyMist induction hob cover.

Before using the induction hob cover, read these operating instructions. Keep them for future reference. These instructions provide important safety warnings, to be observed at all times.

Enjoy your purchase!

### 1. SAFETY INSTRUCTION

**NEVER** place the induction hob cover on a hot surface. After using the induction hob, wait until it has cooled down before placing the induction hob cover.  
**NEVER** switch on the hob when it is still covered with the induction hob cover

**DISCLAIMER:** KitchyMist is in no way liable for damage to the induction hob due to incorrect use of the induction protector.

### 2. FIRST TIME USE

The induction hob cover needs to reach room temperature before straightening. In some cases, this may take a little longer due to different temperatures.

### 3. EXTEND PRODUCT LIFETIME

Roll up the induction hob cover before turning on the hob. It is important to roll up the induction protector - and not to fold it - because this can damage the print.

Do not use the cover as a cutting board, as this can damage the print.

### 4. CARE AND CLEANING

Clean the hob first before placing the induction hob cover, to prevent the bottom of the cover from getting dirty.

To clean the induction hob cover, you can wipe the cover with a clean cloth. You can use detergent if necessary. It is **NOT** recommended to use other cleaning products.