


V113

USER MANUAL



PRODUCT SPECIFICATIONS:



- Wireless: V5.0
- Working distance:10M
- SNR:≥90db
- Battery: 3.7V 1200mah
- Normal volume playing time:3H
- Speaker driver: φ52mm*2
- Power: 4Ω/5W *2
- Frequency response:
150HZ-20KHZ
- Unit size: 75.5 *75.5*161.6mm
- Unit weight:about 512g
- Charging:5V/500MAH

PRODUCT FEATURE

1. International advanced Wireless chip and circuit design techniques, support all wireless devices.
2. With FM function, can search radio station broadcast automatically
3. With Hi-Fi speaker, to make sure the clear and bright sound.
4. Support Micro SD card and USB card, play MP3 format audio.
5. The wireless working distance is 10 meters.
6. With AUX line in, can directly connect the outside devices, for example, tablet PC/TV/cell phones.

KEY AND SLOT FUNCTION

1. Power switch: Press long for power on /power off.
2. DC 5V slot: Use the standard Micro USB V8 charging cable for power charging.
3. TF slot: It can decode and play MP3 format audio when put TF card into the slot.
4. USB slot: It can decode and play MP3 format audio when put the USB card into the slot.
5. AUX line in slot: Use the Mini 3.5 head input through outside devices.
6. When play music, Press short for last song, long press to turn down the volume.



7. When play music, press short for next song, long press to turn up the volume.
8. When play music,(USB card/TF card/Wireless/line in), press short for play/pause.

In FM mode, press short to search station automatically, press again to stop searching. Under Wireless mode with mobile paired,when call coming, press short to answer a call hands-free,press again to hand up,press twice to ring up a call.

9. When play music,(TF card/Line in/USB card/Wireless), short press to switch model.

NOTE: In the FM mode, put in micro charging cable to get

better FM radio station.
USB DISK/ TF CARD should be format FAT32