
SKIP*HOP.

CAMPING CUBS **activity gym**gimnasio actividad • gymnase activités



EN Please retain this information for future reference

ASSEMBLY

Requires assembly by an adult.

- 1. Place mat flat on floor with pattern facing up, and place "arches" on top.
- 2. Select plastic hook (at ends of each arch) and insert into the slots on mat as shown. (A)
- 3. Reach under mat and put the hook through the fabric loop on the bottom of the mat (B).

SAFETY AND DISPOSAL INFORMATION

Substances used in batteries pose environmental and health effects. Dispose of batteries properly. Do not mix waste batteries with other waste. Keep waste batteries separate. Do not dispose of by landfill or by incineration. Return waste batteries to your point of purchase or recycle center. Recycle all waste batteries per local regulation.



Do not dispose of batteries in trash. They are to be collected separately in accordance with local law