






























INSTRUCTION MANUAL

A1  2.9x19 2pcs	A2  3.5x9.5 10pcs	A3  3.5x25 12pcs	B  2pcs	C  2pcs	
D  1pc	E  1pc	F  1pc	G  1pc	H  2pcs	I  1pc
J  3pcs	K  3pcs	L  2pcs	M  1pc	N  1pc	O magnet  3pcs
P  3pcs	Q  1pc	R  1pc	S  1pc	T  1pc	U  1pc
V1  4pcs	V2  4pcs	W  1pc	X1  4pcs	X2  1pc	Y  1pc

ASSEMBLY/MONTAGE/ASSEMBLAGE/MONTAJE

