



#20491

Manette de jeu pour PC et PS3

Manette de jeu sans fil pour PC et PS3 avec batterie rechargeable et prise solide pour une expérience de jeu confortable

Principales caractéristiques

- Portée sans fil de 10 mètres
- 13 boutons, 2 joysticks et une croix directionnelle
- Rechargeable par port USB (câble fourni)
- Revêtement en caoutchouc pour une prise en main parfaite
- Boutons sensibles à la pression (PS3 uniquement)
- Indicateurs PS3 et bouton accueil



Qu'y a-t-il dans la boîte

- Manette de jeu avec batterie intégrée
- Récepteur USB
- Câble de charge USB
- Mode d'emploi
- Autocollant de la gamme de jeu

Configuration requise

- PC/ordinateur portable avec Windows 10, 8 ou 7
- PlayStation 3
- Port USB

10 METER
WIRELESSRECHARGEABLE
BATTERYDIRECT INPUT-
X INPUT

GÉNÉRAL

Driver needed	False	Height of main product (in mm)	65 mm
Width of main product (in mm)	150 mm	Depth of main product (in mm)	110 mm
Total weight	204 g		

CONNECTIVITY

Connection type	Wireless	USB version	1.0
Wireless range	10 m	Wireless receiver included	True

POWER

Batteries included	False	Rechargeable battery	True
Battery life (hours)	4 - 8 hours		

INPUT

Power source	Battery, micro-USB
---------------------	--------------------

AUDIO

Built-in speaker	False	Headphone connection	False
-------------------------	-------	-----------------------------	-------

CONTROL

Controls	Directional pad	Number of buttons	13
Shoulder buttons	True	Trigger buttons	True
Pressure sensitive buttons	True	Analogue stick	True
Turbo fire	False	Vibration	No
x-input / direct input	D-input, x-input		

COMPATIBILITY

Compatible Device Types	Gaming console, laptop, pc	Compatible Consoles	PS3
Compatible Software Platforms	Windows		

FEATURES

Software	False
-----------------	-------



PRODUCT VISUAL 1



PRODUCT ESHOT 1



PRODUCT FRONT 1



PRODUCT VISUAL 2



PRODUCT SIDE 1



PRODUCT TOP 1



LIFESTYLE VISUAL 1



PACKAGE VISUAL 1



PACKAGE FRONT 1