
## Mobile Air Conditioner





Mobile

TL-9001

. Stand unit

upright and

remove the

carton by

lifting it

Air Conditioner

How to Open The Box

2. Leave the


Air Conditioner


2 Hours


in upright position for

at least two

turning on.










## Mobile

Air Conditioner TL-9001

How to Open The Box










TL-900

- 2.64 KW Portable Air Conditioner
- Ergonomic Handle for Easy Portability
- 2 Fan Speeds
- **Advanced Rotary Compressor Technology**



- 24 Hour Timer
- Remote control
- **Durable casters**





Dimensions: 354L x 338D x 698H NetWeight: 22Kg **Power supply: 220-240V / 50Hz** 

RoHS CE Z

## Mobile

Air Conditioner


How to Open The Box


TL-9001

- 2.64 KW Portable Air Conditioner
- Ergonomic Handle for Easy Portability
- 2 Fan Speeds
- **Advanced Rotary Compressor Technology**



- 24 Hour Timer
- Remote control
- **Durable casters**







Dimensions: 354L x 338D x 698H NetWeight: 22Kg **Power supply: 220-240V / 50Hz** 

384.00 mm





400.00 mm