

Charging table lamp instructions

Warning:

This lamp is equipped with rechargeable lithium battery. The battery should not be exposed to heat and sunlight.

Please do not use it when charging. Under no circumstances should the lamps be modified or stressed. Any change will lead to security and loyalty. The manufacturer is not responsible for any modified products



Be careful:

Please carefully read the product use and maintenance instructions; Use according to the maintenance instructions to ensure the safety of the product, and keep the maintenance instructions properly. We will not assume any responsibility for the man-made damage caused by improper use, and all kinds of damages caused thereby are not covered by the warranty, and any changed products will not. Do not put the product into water or take it with wet hands. -In case of any fault or damage, please stop using immediately and contact the local dealer or qualified technician. The rated input current is 100 - 240V~50/60Hz, and the rated output current is 5V DC (type-c) 2A. The specified charger must be used

Maintenance:

If it is damaged, please select the cable with the same characteristics as the original cable. Do not connect the power supply when cleaning the lamp. Remember to use soft cloth and neutral detergent or soap solution. Avoid using alcohol or detergent containing acetone, thioberyllium, ammonia or any solvent. Avoid mechanical pressure and heavy contamination. Protection grade Ip54: prevent dust from entering - prevent water splashing. The replacement service of lamp source can only be provided by the manufacturer.

Operating Instructions Light trigger:

touch the top of the lamp to switch the light (long press to adjust the light on or off) (see the schematic icon on the page) When the battery has no power, it can be used in indoor environment with IP20 protection level through USB connection cable. Applicable to IP54 outdoor space. Do not overturn the product when it is placed on a horizontal solid surface.


Battery charging:

The USB cable is connected to the charging port of the lamp base, and the other end is connected to the power socket (5V adapter must be used). The red light indicates charging, and the green light indicates charging. Please charge continuously for more than 5 hours to ensure the best power. It can be used continuously for about 6 hours after being fully charged. We recommend that the battery be fully charged and discharged during the first 10 times of use to ensure the best condition of the battery. Please charge as soon as possible when the battery is exhausted; The battery life will be shortened if there is no electricity for a long time. Battery replacement:

Use original rechargeable batteries.

Under no circumstances should you use conventional batteries, which may cause danger. If you need to replace batteries, please contact the manufacturer or dealer!

可台 充灯 电说 明书



警示:

这款灯安装有可充电的锂电池, 电池不可暴露在热源和阳光下, 充电时请勿使用。在任何情况下切忌对灯具进行改造或重压, 任何变更都会引发安全隐患, 制造商不对任何改装产品承担责任。

注意:

请仔细阅读产品使用和保养说明; 按照保养说明使用才能确保产品的安全性, 妥善保管保养说明书。制造商因使用不当引起的人为损坏不承担任何责任, 因此引发的各种损坏也不在保修范围, 任何变更产品都不具备保修。忌将产品放入水中或使用潮湿的手拿取。发现有任何故障、损坏时请立即停止使用, 联系当地经销商或有资质的技术人员。

充电器额定输入电流100 - 240V~ 50/ 60Hz, 额定输出电流5V type-c 2A, 务必使用规定要求的充电器和电缆。

保养和维护:

如果充电线有损坏, 请选用与原电缆相同特性的电缆, 灯具在清洁时请不要连接电源, 切记用软布和中性清洁剂或皂液进行清洁。避免使用酒精或含有丙酮、硫酸、氨或任何溶剂的清洁剂。避免机械压力和重污。防护等级IP54: 防止灰尘进入-防止溅水。

灯具光源的更换服务仅能由制造商提供。

操作说明

灯光触发: 1. 触摸灯底部弧形处切换灯光

2. 16色遥控款为遥控器调节(见页面示意图标)

当电池没有电时可以通过USB连接线在防护等级IP20的室内环境使用。

适用于IP54等级户外空间。将产品放置于水平固体表面切忌翻倒。

电池充电

请将USB线接到灯底座的充电口, 另一头连接电源插座(务必使用5V适配器), 红色灯表示正在充电, 绿灯表示充满。产品充电, 请把灯关掉再进行充电。请连续充电5小时以上以保证最佳的电量。充满一次电可连续使用约18小时。我们建议在前10次使用时充分充电以确保电池最佳状态。电量耗尽时请尽快充电; 如果电池长时间没有电会缩短电池寿命。

电池更换

请使用原装充电电池, 在任何情况下切忌使用常规电池, 这可能导致危险, 如需更换电池请联系制造商或经销商!