

WARRANTY

Thank you for purchasing the Qware Charging Dock.
The product has warranty for two years. Our customer service will reply to you as soon as possible.

For questions and information: qware.nl

Model: QW XBS-7000

Distributed by:
Pirox International B.V.
www.qware.nl
6, 3011 TA Rotterdam
The Netherlands

Specifications are subject to change
without prior notice. Made in China



SUITABLE FOR **XBOX™ SERIES X/S**



CHARGING DOCK

USER MANUAL



CHARGING DOCK



Product description:

- With 2 × 800mAh rechargeable battery packs.
- There are multiple charging methods, you can directly charge the battery or place the controller on the charging base.
- Long battery life, long game time.
- The LED indicator tells you the status of the charging station.

CHARGING DOCK

SPECIFICATIONS

Cable length:	3 meter USB-A to USB-C cable
Input:	5V/2A
Output:	5V/1.5A
Product size:	65x205x65mm
Charging methode:	2 pins
Charging time:	3 hours (only with 5V2A input)
Input voltage:	DC 5V
Battery pack capacity:	2 x 800mAh
Compatible with Xbox™ Series X/S controller	

Content:

- 1x Dual charging dock
- 2x 800 mAh batteries
- 1x 3m USB-A to USB-C cable

CHARGING DOCK

PROCEDURE:

1. Use the USB charging cable to connect the power connector.
2. Insert the supplied battery pack into the battery compartment of the Xbox™ Series X/S controller.
3. To charge the Xbox™ Series X/S controller, place it on the charging station freely and let the metal contacts of the battery pack fully contacted to the charging station.
4. The charging indicator will glow red during charging procedure.
5. After fully charged, the indicator will change to green.

CHARGING DOCK

TROUBLE SHOOTING:

Correctly use the Xbox™ Series X/S Controller Charging Station :

1. Make sure that the Xbox™ Series X/S controller is firmly placed on the charging contacts.
2. Ensure that the battery pack is correctly inserted into the battery compartment of the Xbox™ Series X/S controller.

CHARGING DOCK

NOTED:

1. Please fully charge the battery before the first time use to maximize the life time of the battery packs.
2. Please use the included battery only. Use of other battery pack may cause the damage, failure or fire of batteries, controllers or console.
3. Protect the power supply and USB charging cable from dust, moisture, liquid, high temperature, direct sunlight.
4. Do not touch the connector and USB charging cable of the product with your fingers or metal objects.
5. Do not dismantle the charging dock, battery or charging cable at any time.
6. Do not throw the battery into fire this may cause explosion!
7. Please dispose batteries according your local regulations.

CHARGING DOCK
