




User Manual



Remove Clock Protection Clip

2



Remove LEDs Battery Clip

3






Charge regularly. Min. 1x per 30 days

Auto-standby after 15min.

* Depending on the Audio Intensity



All on



Rotating



Random



Sound Active



Collect your favourite colorstraps