

Quick.guide

Installation of your heating product

1 Charge The.Powerbank up to 4 lights.
(use 5V/2A adapter)



2

Open the heating product and place the cable in The.Powerbank (you'll find it in the bag of the inner cover).

3

The on/off button on the outer cover flashes.



4

Press the on/off button on the outer cover for 3 sec. The.Powerbank is on and the button fades red.



5

Place The.Powerbank in the bag of the inner cover and close the zipper of both covers.



Wanna know more?



Quick.guide

Good to know!

6



The heating product needs 10 minutes before the heating elements are fully heated. When heated the button turns blue.

7

There are 3 settings:

- 35 - 38 °C
- 38 - 40 °C
- 40 - 45 °C



Only the outer cover can be washed in the washing machine at 30 degrees. Carefully press the on/off button out of the outer cover. Do not use a dryer!

8

When you turn off your heating product (press on/off button for 3 seconds) and you leave the Powerbank connected, the button flashes from time to time (standby-mode).



9

It is not necessary to put the Powerbank in here when you use your heating product indoors. When you are on a boat it's handy to use the wallet.

10

Wanna know more?



Where you can find our HQ

Nikki.Amsterdam
Mollerusweg 15
2031 BZ Haarlem

Having any trouble?

service@nikki.amsterdam