

## Shiatsu Massage Mat C€



Instruction Manual

## Warning:

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

The appliance is only to be used with the unit provided. It must only be supplied at SELV.

The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.

## The instructions on safe use and handling:

The instructions that need special attention during installation.

Please keep this instruction manual for future use.

Disassembling the controller can cause harm and a risk.

If the current or the temperature fuse is open, please contact the manufacturer or the sales representative.

Please inspect often for damage. If a damage or incorrect usage is discovered, discontinue use and notify the manufacturer.

The device is not designed for medical use in a hospital.

The safety precautions enclosed must be followed to prevent the risk of fire, electric shock or injury.

- Do Not Use if the power cord is damaged. Do not try to fix this. Only use a qualified person to avoid any hazard.
- Before turning on, ensure that the plug is in a suitably grounded outlet.
- Do Not use this appliance outdoors or in the bathroom.
- When the appliance is not in use, make sure that it is switched off and unplugged from the power outlet.
- To reduce the risk of electrocution, never operate this product with wet hands, submerge under water or spill liquids onto the product.
- Do Not place any sharp objects onto the massage mat.
- Do not kink or damage the power cord.
- Do not try to repair or modify this appliance. Seek professional advice.
- Do not operate the appliance near liquids (kitchen sink, water basins, taps etc).
- Do not use this appliance with an extension cord, unless checked and tested by a qualified electrician.
- Never leave the appliance unattended while switched on.
- Do not use your massager if it or its cord or controller has been damaged.

1