

NORD + BARE

Hair Trimmer

Compact to fit in a small
purse or bag



Safe and painless on all areas.
Great for the face, bikini line,
tops of toes and anywhere
else you need it !



Extra-fine blade for precise
trimming of delicate areas



FOR BATTERY REPLACEMENT

Turn the power switch off. Open battery compartment
on the bottom of the unit. Replace AAA battery.
BATTERY NOT INCLUDED.

For a complete guide on usage, battery replacement
and cleaning details, see instructions inside.

Specifications

Material: Hair Body-ABS+PC Cutter Head-Stainless steel
Battery Capacity: 1xAAA
Input: 1.5V/3A
Output: 0.6W



MADE IN CHINA