




INSTALLATION METHOD




Step 1
Install the four brackets from the bottom




Step 2
Install 2 transmitters




Step 3
Firmly push and twist the hose and air pump together until they are attached.



Step 4
Place both rockets on the launch tubes, sliding it all the way down. your Stomp Rocket is ready for lift off!



Step 5
Position the air pump flat side down (curved side up).



Step 6
Running, jumping, Stomping