






INSTALLATION METHOD



Step 3
Firmly push and twist the hose and air pump together until they are attached.



Step 5
Position the air pump flat side down (curved side up).

