



Rexel 2104511 Style A4 Home and Office Laminator Instructions

October 30, 2021 November 2, 2021

[Home](#) » [Rexel](#) » Rexel 2104511 Style A4 Home and Office Laminator Instructions 


*Rexel 2104511 Style A4 Home and Office
Laminator Instructions*

STYLE

A4 & A3 LAMINATOR

start here





⚠ Please read and keep these important safety instructions

- Only use the unit for its intended purpose.
- Do not touch the heating plate of this unit as it may be hot.
- The unit must only be connected to a supply voltage corresponding to the electrical rating shown on the unit.
- Unit should be connected to a socket outlet near the equipment that is easily accessible.
- Do not connect to multi adaptors or use with an extension cable.
- Failure to follow these instructions could result in damage/injury and will invalidate your guarantee.
- Do not attempt to service or repair the unit yourself.
- In the event of a fault, unplug the unit and contact an authorized GBC service representative for any required repairs.
- Do not use this unit if the cable or plug have been damaged.

Contents [[hide](#)]

1 Cleaning

2 Service

3 Guarantee

4 Documents / Resources

4.1 References

4.2 Related Manuals / Resources


Cleaning

 **WARNING: UNPLUG THIS PRODUCT BEFORE CLEANING THE EXTERIOR. WIPE EXTERIOR ONLY WITH A DAMP CLOTH AND DO NOT USE DETERGENTS OR SOLVENTS.**

Regularly feed a cleaning card or sheet of paper through the laminator to clean the rollers. Cleaning sheet order code: EK50000.

Service

For details of your local service representative, see back page.

 Only use the laminator in indoor areas.

 Products marked with this symbol meet all applicable Community regulations for the European Economic Area.

Waste Electrical and Electronic Equipment (WEEE)

At the end of its useful life, your product is considered to be WEEE. As such, it is important to note that: WEEE is not to be disposed of as unsorted municipal waste. It is to be collected separately such that it can be disassembled so its components and materials can be recycled, re-used, and recovered (burned for energy content in the production of electricity).

Public collection points have been set up by municipalities for the collection of WEEE, free of charge to you.

Please return your WEEE to the collection facility nearest your home or office.

If you have difficulty locating a collection facility, the retailer that sold you the product should accept your WEEE.

If you are no longer in contact with your retailer, please contact ACCO for assistance with this matter.

Recycling of WEEE is geared toward protecting the environment, protecting human health, preserving raw materials, improving sustainable development, and ensuring a better supply of commodities in the European Union. This will be achieved by retrieving valuable secondary raw materials and reducing the disposal of waste. You can contribute to the success of these goals by returning your WEEE to a collection facility.

Your product is marked with the WEEE symbol (wheelie bin with an X through it). This symbol is to inform you that the WEEE is not to be disposed of as unsorted municipal waste.

Guarantee

Operation of this machine is guaranteed for one year from date of purchase, subject to normal use. Within the guarantee period, ACCO Brands Europe will at its own discretion either repair or replace the defective machine free of charge. Defects due to misuse or use for inappropriate purposes are not covered under the guarantee. Proof of date of purchase will be required. Repairs or alterations made by persons not authorized by ACCO Brands Europe will invalidate the guarantee. It is our aim to ensure that our products perform to the specifications stated. This guarantee does not affect the legal rights which consumers have under applicable national legislation governing the sale of goods.

Service

ACCO Service Division

Hereward Rise, Hales Owen, West Midlands, B62 8AN 0800 279 5102 service.uk@acco.com
www.gbceurope.com/service

ACCO Brands Benelux B.V.

Holtum Noordweg 11, 6121 RE Born, Holland 08000 234 931 service.nl@acco.com
www.gbceurope.com/service

FR ACCO France

08 05 63 02 55 service.fr@acco.com
www.gbceurope.com/service

AU ACCO Austria

0800 677671 service.at@acco.com
www.gbceurope.com/service

DK ACCO Brands Nordic AB

80 251495 service.nordic@acco.com
www.gbceurope.com/service

FI ACCO Brands Nordic AB

0800 915871 service.nordic@acco.com
www.gbceurope.com/service

IS ACCO Brands Nordic AB

800-7407 service.nordic@acco.com
www.gbceurope.com/service

LV ACCO Brands Nordic AB

8000-4993 service.nordic@acco.com
www.gbceurope.com/service

BE ACCO Brands Benelux B.V.

0800 48352 service.be@acco.com
www.gbceurope.com/service

LU ACCO Brands Benelux B.V.

800 27649 service.lu@acco.com
www.gbceurope.com/service

PT ACCO Iberia SLP

800 8 55955 service.ib@acco.com
www.gbceurope.com/service

CH ACCO Schweiz

0800 001790 service.ch@acco.com
www.gbceurope.com/service

DE ACCO Brands Benelux B.V.

08007238504 service.de@acco.com
www.gbceurope.com/service

ES ACCO Iberia SLP

800 300655 service.ib@acco.com
www.gbceurope.com/service

IE ACCO Service Division

0800 939 254 service.ie@acco.com
www.gbceurope.com/service

IT ACCO Brands Italia S.r.l

800029359 service.it@acco.com
www.gbceurope.com/service

NI ACCO Service Division

08002795103 service.uk@acco.com
www.gbceurope.com/service

NO ACCO Brands Nordic AB

800 10953 service.nordic@acco.com
www.gbceurope.com/service

PL Poland

00-800-1215218 service.pl@acco.com
www.gbceurope.com/service

SE ACCO Brands Nordic AB

0200899942 service.nordic@acco.com
www.gbceurope.com/service

HU ACCO Hungarian Kft

06-800-20886 service.hu@acco.com
www.gbceurope.com/service

CZ Czech Republic

00-800-44858150 service.cz@acco.com
www.gbceurope.com/service

RU

« . » 8-10-8002-5585011 service.ru@acco.com www.gbceurope.com/service

ZA Rexel Office Products (PTY) Ltd

011 837 7723 service.za@acco.com
www.gbceurope.com/service

IN GBC Asia Pte Ltd

6776 0195 Singapore. Webmaster@acco.com
www.accobrandsasiasia.com

JP ACCO Brands Japan K.K.

03 5351 1801 service.jp@acco.com
www.gbceurope.com/service

AU Pelican Artline PTY LTD

1300 ARTLINE custsupport@pelikanartline.com.au www.pelikanartline.com.au

NZ Pelikan Artline PTY LTD

0800 800 526 customersupport@pelikanartline.co.nz www.pelikanartline.co.nz

Ref: Style / CBT12698 Issue: 1 (07/16)



ACCO Brands Europe Oxford House Eynesbury HP21 8SZ United Kingdom
www.accobrand.com

Documents / Resources



[Rexel 2104511 Style A4 Home and Office Laminator](#) [pdf] Instructions
2104511, Style A4 Home and Office Laminator, 2104514, Style A3 Home and Office Laminator

References

- [Bookbinders | Online Stationery Store Australia | Brisbane Store](#)
- [ACCO Brands Chevron Icon Icon/Social/Facebook Instagram icon Icon/Social/Twitter Icon/Social/LinkedIn RSS icon](#)
- [404 Page Not Found](#)
- [ACCO Brands Asia - Singapore Leading Supplier In Quality Office Products & Supplies](#)

Related Manuals / Resources



[Lacie W68729777 Adjustable Height Laptop Desk for Home Office WorkStation Instruction Manual](#)

MOUNTING INSTRUCTIONS Model: W68729777 Max load: 10kgs During Moving SCREW PACKAGE PARTS INCLUDED INSTALLATION



[CHAIRMAN Office Chair Instructions](#)

CHAIRMAN Office Chair Instructions support@neochair.com
www.neochair.com Parts Instructions User Manual Cautions Enjoy your new favorite chair Our goal...



[Shure MV5C Home Office Microphone User Manual](#)

MV5C Home Office Microphone General Description The Shure MV5C microphone connects directly to a computer over a USB...



[Alpine Style Solution for Audi A4, A5, Q5 Owner's Manual](#)

Alpine Style Solution for Audi A4, A5, Q5 Getting Started Location of Controls (AUDIO)/(Favorite) button: Displays the Audio/Visual...

[Manuals+,](#)

- [home](#)
- [privacy](#)