
ICSEE WiFi Camera Quick Manual for Android and iOS






Packing list

accessories as below:

After open packing list box, please check product body and

Before use, please pay attention to the interface and button of camera.



Reset button: Long press to restore the camera to factory settings.


1.Download APP

Tips one: Scan QR code.



Tips two: Search "iCSee" in the App store and download.

Use the power cord to connect the camera to the power adapter




If you need local storage, please install the memory card firstly. then power on the device (the memory card does not support hot swapping, please plug and unplug the memory card when the device is powered off). Cloud storage is recommended, which is safe and convenient. Details See "Step 4" for operation.

3.Camera configuration

Connect your phone to WiFi.



and turn on the power, as shown in the figure below.





 After successful login. Click the "+" button (Figure 2). Click the "WiFi Camera" (Figure 3). 01.User login

Open the iCSee app, register an account and login(Figure 1).

Figure 1

Log In

Username UserName/Email

Save PW

Password Please Input Password

— Quick Login —

🎭 f 🥯 🌡

...; ⊠ 🕏 🖼

Auto Login

Forget Password

to factory settings and then configure the network.

02.Quick configuration



Figure 3 Smart Device Add Device WiFi Camera Wireless Base Station From sharing Click "+" button to add device Other distribution networks and adding methods

Set network configuration according to the camera's voice

prompts and the APP interface step-by-step guide. When the

that the camera has successfully configured the network.

Note: If the camera does not have a prompt sound for a long time, you can

press and hold the camera Reset button until you hear the prompt "Restore

factory settings, please do not power off "and release it to restore the camera

camera emits a "Connect router successfully" prompt, it means


instructions on the APP interface to set the camera password

After the configuration is completed, the device is displayed in

Smart Device

After the network configuration is successful, follow the

the device list interface. Click to open the real-time preview screen, and carry out relevant operations and settings(Figure 4 Figure 4



4.Cloud storage Steps to open cloud storage: click the "cloud storage" or "cloud"

icon in the device list interface (Figure 5), and follow the guidance of the app interface to understand and open the cloud storage package, with a variety of packages available. Figure 5



Q: How do cameras store video?

be careful.

A: 1.Local TF card storage, maximum support up to 128G TF

- card after full automatically delete earlier video, overwrite 2.Cloud storage.

A: Re-connect and set a new password after the device is

Q: what should I do if forget the device password?

restored to factory settings. Note: The device password involves privacy security, please

Q: How to do if the camera is not connected or offline?

- A: 1.Check if the camera power or network of router normally.
- 2.Plug the camera power to restart camera.
- 3. Restore the camera to factory settings.

Q: Is 5g router supported?

is xxxxx-5G), please connect WiFi of mobile phone to hotspot of xxxxx-2.4G of router before configuring camera.

A: If you use 5g router, 5G and 2.4G use the same connection hotspot (that is, SSID is the same), you can connect directly. If 5G and 2.4G are not the same connection hotspot (that is, SSID is different, generally SSID of 2.4G is xxxxx-2.4G, SSID of 5G

- 2. The APP and product firmware will be updated from time to
- that are inconsistent with product functions or printed errors.



avoid being misappropriated by criminals.

⚠ Notice

- 2. Do not install the device in a place that is damp, dusty, or
- accessible to children. 3. Please use and store within the allowable temperature and
- humidity range, and do not disassemble the equipment at will.

1. Please refer to the actual product, the manual is for reference

3. The manual may contain technically inaccurate parts or parts

- time. You can upgrade to the latest firmware online by yourself without notice. The manual is for reference only.
- Please refer to our company's final interpretation..