


## USER MANUAL

# I Love Me

## HAIR DRYER & VOLUMIZER

### A Big Thank You

We're thrilled that you have chosen to purchase the Blower Brush Hair Dryer. We're committed to providing you with products that enhance your daily life. We aim to give our customer excellent support. Should you have any questions or feedback about your new product, simply get in touch with our customer support team. Enjoy your new product!



### IMPORTANT MESSAGE TO CONSUMERS THIS MESSAGE ABOUT GROUND FAULT CIRCUIT INTERRUPTERS CAN SAVE A LIFE



### IF YOU MUST USE YOUR HAIR DRYER IN THE BATHROOM, INSTALL A GFCI NOW!

This message is from the Consumer Product Safety Commission (CPSC) and the Electrical Apparatus Service Foundation (EAF). It is intended to help consumers prevent electrical shock injuries in the bathroom. The CPSC and EAF recommend that all electrical devices used in the bathroom be protected by a ground fault circuit interrupter (GFCI). This device can help prevent electrical shock injuries. If you must use your hair dryer in the bathroom, install a GFCI. A GFCI is a safety device that helps prevent electrical shock injuries. It is a simple and inexpensive way to protect yourself and your family.

### AUTOMATICALLY TURN OFF YOUR HAIR DRYER TO AVOID FIRE - INSTALL GFCI

The CPSC and EAF recommend that all electrical devices used in the bathroom be protected by a ground fault circuit interrupter (GFCI). This device can help prevent electrical shock injuries. If you must use your hair dryer in the bathroom, install a GFCI. A GFCI is a safety device that helps prevent electrical shock injuries. It is a simple and inexpensive way to protect yourself and your family.

### SAFETY INSTRUCTION

- Brush/Bristle area will be hot. DO NOT TOUCH THIS AREA WHILE APPLIANCE IS IN USE.
- Do not use the device if it is defective or the cord is damaged.
- Unplug and store the device in a safe and dry environment after each use.

### OPERATING INSTRUCTIONS

- Prior to plugging in, check the voltage on the rating label to ensure it corresponds with your household hair's voltage.
- The brush is equipped with three heat settings - low/middle/high - which are controlled using the side button. Use the high speed setting for rough drying of thicker hair, and the medium setting for finer and more precise control when styling. The side button of the device to set the style.

### WARRANTY POLICY INSTRUCTIONS

- Products are manufactured to the highest standard and will provide you with superior performance when used in accordance with the instructions in the manual. Our product comes with a 1-year warranty.

### HAIR DRYER & VOLUMIZER