




PURE Pleasure



Jouw plezier, onze passie!



Operating Instructions (Choose the combination of modes you want):
Note: Before using the remote control, please start the trusting dildo through the button at the bottom of the trusting dildo ①.

1. Remote Control Mode

1.1 Turn on the dildo with remote control

Open the battery compartment to remove the protective film on the battery, and insert the battery according to the + pole. Short press the ON/OFF button of the remote control ①, and the remote standby mode will be activated after the light prompt which means the dildo can be controlled with a remote control.

1.2 Turn off the dildo with remote control

When in standby or use mode, long press the ON/OFF button ② of the remote control to turn off the dildo.

When the dildo has a vibration prompt and the light goes out, it means the power of the dildo is off.

1.3 Select Thrusting & Rotation Function

Short press thrusting /vibration button ② to cycle through the thrusting and vibration mode. 5 thrusting and rotation modes can be selected.

1.4 Select Vibration Function

Short press the ON/OFF ③ button to start the remote control mode, you can select the vibration mode by short pressing the button again, 10 vibration modes can be selected.

1.5 Select Heating Function

Short press the heating button ④ to start the heating function.

2. Manual Mode

Step1 Press the power button on the button of the dildo to start the dildo.

Step2 After starting, short press the button on the button of the dildo to cycle to adjust the required mode.

Step3 Press and hold for the power button three seconds to turn off the dildo.

3. Charging method

Connect the charging cable to the USB charging head (you can use the mobile phone charging head or bring your own), suck the magnetic charging head to the magnetic charging port on the back of the penis testicle. The red light flashes to indicate charging.

Specifications:

1. Rated voltage 3.7V, rated current 8A
2. Material: Liquid silicone
3. Waterproof: life waterproof
4. Charging time: about 2 hours to full, can be used continuously for about 45-60 minutes
5. Remote control battery: 12V 27A

Package Content:

Vibrator*1
Charging cable*1
Remote control*1
Manual*1

Warning:

1. It is recommended to use lubricating fluid for the first time when using it.
2. Make sure to turn off the power of the dildo and the remote control after use, so as not to affect the use of the battery.
3. Wash with clean water or neutral detergent after use, and dry in a ventilated place after washing.
4. The product is waterproof for life, so it is not recommended to use it directly in water.
5. The heating time is about 4-5 minutes, please use it with caution for people who are sensitive to heat.

Disclaimer

The Pure Pleasure Dildo Vibrator is designed for personal pleasure. By using this product, you agree to the following terms:

1. Health & Safety

- This is not a medical device. Consult a doctor if you have health concerns.
- Do not use if you have heart conditions, epilepsy, are pregnant, or have medical implants without professional advice.
- Avoid use on irritated skin or open wounds. Discontinue if discomfort occurs.

2. Hygiene & Maintenance

- Clean before and after use with mild soap and water or a toy cleaner.
- For personal use only—sharing may increase the risk of infection.
- Store in a dry, cool place, away from direct sunlight.
- Use water-based lubricants only to prevent material damage.

3. Usage & Safety

- For adult use (18+) only. Keep out of reach of children.
- Do not use under the influence of alcohol, drugs, or sedatives.
- Stop immediately if pain, numbness, or irritation occurs.
- Avoid excessive or prolonged use.

4. Charging & Battery Safety

- Charge only with the provided USB cable and a compatible adapter (5V, 1A).
- Never charge in wet conditions.
- Do not leave unattended while charging or overcharge.
- Dispose of properly—contains a non-replaceable lithium battery.

5. Waterproof Use

- Water-resistant (IPX5), safe for use in humid conditions.
- Do not fully submerge. Dry thoroughly before charging.

6. Liability & Warranty

- Use at your own risk. We are not responsible for misuse or damages.
- Warranty covers defects under normal use. Damage due to improper cleaning or overcharging voids the warranty.

7. Privacy & Discretion

- Shipped in discreet packaging to protect your privacy.

By using the Pure Pleasure Dildo Vibrator, you confirm that you have read and understood this disclaimer. Enjoy responsibly!



2

3

4