




TRUELIFE

# **Gebruikershandleiding**

## **Slaaptrainer - Knuffeldier**

# Handleiding: Knuffel met muziek, sterrenprojector & White Noise voor kinderen & baby's

*In onderstaande handleiding wordt de afbeelding van de uil gebruikt als illustratie. Indien u een ander knuffeldier heeft gekocht zal alles hetzelfde werken echter zal het knuffeldiertje zelf uiteraard anders zijn. Namens het TrueLife team wensen wij u veel plezier toe met uw aankoop!*



Afbeelding 1

1. White noise knop
2. Volume knop
3. Sterrenprojector knop
4. Muziek aan/uit
5. Sterrenprojector
6. Knuffel



Afbeelding 2

1. De batterijen zitten veilig bevestigd met een clip en schroef. De schroef kunt u eenvoudig met een kleine schroevendraaier losdraaien.
2. Batterijhouder

**Bewaar deze informatie a.u.b. voor toekomstig gebruik**

**Veiligheidswaarschuwingen**

1. De batterijen mogen alleen geplaatst en verwijderd worden door een volwassene. Houd de batterijen altijd uit de buurt van kinderen.
2. De white noise machine en sterrenprojector en de knuffel dienen voor de veiligheid weggehouden te worden van water en/of vuur.
3. De niet-oplaadbare batterij die is meegeleverd mag niet worden opgeladen. Er mag alleen een batterij van hetzelfde of een gelijkwaardig type worden gebruikt.
4. De batterij moet met de juiste polariteit worden geplaatst. Een lege batterij moet uit de white noise machine en sterrenprojector verwijderd worden en kan worden ingeleverd bij een inzamelpunt ([www.legebatterijen.nl](http://www.legebatterijen.nl))
5. De voedingsklemmen van de batterij mogen niet worden kortgesloten. Gebruik geen oplaadbare batterij en gebruik geen oude en nieuwe batterijen door elkaar. Gebruik geen combinatie van standaard alkalinebatterijen (zinkkoolstof) of oplaadbare batterijen (nikkelcadmiumbatterijen).
6. Verwijderen de batterijen als de White Noise Machine en sterrenprojector niet wordt gebruikt. Ook lege batterijen moeten verwijderd worden.

### Eenvoudig wasbaar

Nadat de white noise machine en sterrenprojector uit de knuffel is verwijderd, is kan de knuffel gewassen worden (Afbeelding 3).



Afbeelding 3

### Gebruiksaanwijzing

1. De white noise machine en sterrenprojector bevat 10 Verschillende slaapmuziekjes. Met knop 1 kan het gewenste geluid worden afgespeeld. (afbeelding 1)
2. De white noise machine en sterrenprojector bevat 3 natuurlijke slaapgeluiden namelijk: hartslag, waterval, natuur. Met knop 1 kan het gewenste geluid worden afgespeeld. (afbeelding 1)
3. De white noise machine en sterrenprojector bevat 3 Volume standen. Met knop 2 kan het gewenste volume worden gekozen. (afbeelding 1)
4. De sterrenprojector heeft 4 verschillende kleuren. De gewenste kleur kan worden ingesteld met knop 3. (afbeelding 1)
5. De white noise machine en sterrenprojector schakelt na 30 minuten automatisch uit.
7. De white noise machine werkt op 3 AAA batterijen. Deze zijn niet oplaadbaar.



TRUELIFE

**User manual**  
**Sleep trainer - Cuddly toy**

## Manual: Cuddly toy with music, star projector & white noise for kids & baby's

*In the guide below, the owl image is used as an illustration. If you have bought another stuffed animal, everything will work the same, however, the stuffed animal itself will of course be different. On behalf of the TrueLife team, we wish you a lot of fun with your purchase!*




Image 1

1. White noise button
2. Volume button
3. Star projector button
4. Music on / off
5. Star projector
6. Toy



Image 2

1. The batteries are securely attached with a clip and screw. The screw can be easily loosened with a small screwdriver.
2. Battery holder

**Please keep this information for future reference**

**Security warnings**

1. The batteries are only to be inserted and removed by an adult. Always keep the batteries away from children.
2. The white noise machine and star projector and the stuffed animal should be kept away from water and / or fire for safety.
3. The non-rechargeable battery provided is not to be recharged. Only a battery of the same or equivalent type may be used.
4. The battery must be installed with correct polarity. An empty battery must be removed from the white noise machine and star projector and can be handed in at a collection point ([www.legebatterijen.nl](http://www.legebatterijen.nl))
5. The battery power terminals must not be shorted. Do not use a rechargeable battery or mix old and new batteries. Do not use a combination of standard alkaline (zinc carbon) or rechargeable (nickel-cadmium) batteries.
6. Remove batteries when the White Noise Machine and Star Projector is not in use. Dead batteries must also be removed.



Image 3

### **Easily washable**

The white noise machine and star projector can easily be removed from the toy. When the white noise machine and star project has been removed, the cuddly toy is washable (Image 3).

### **Instructions**

1. The white noise machine and star projector contains 10 different sleep music. The desired sound can be played with button 1.
2. The white noise machine and star projector contains 3 natural sleep sounds namely: heartbeat, waterfall, nature. The desired sound can be played with button 1.
3. The white noise machine and star project contains 3 Volume settings. The desired volume can be selected with button 2.
4. The star projector has 4 different colors. The desired color can be set with button 3.
5. The white noise machine and star projector will turn off automatically after 30 minutes.
7. The white noise machine and starprojector works on 3 AAA batteries. These are not rechargeable.