

UNIQ BUDS PRO

www.uniqaccessory.com

UNIQ Buds Pro TWS Bluetooth Earbuds are perfect for anyone who likes freedom of movement, without excess cables. The design is stylish and the music quality is premium.




The UNIQ Buds Pro earplugs come with a handy charging case in a matching colour. Thanks to its ergonomic design, it fits perfectly in your ears and gives you the ultimate wearing experience.





Please remove the sticker on the back cover of the earphones for better performance.



GET TO KNOW THE BUDS PRO







- 1- Microphone
- 2- Indicator light 1
- 3- Touch area
- 4- Ear cap

- 5- Indicator light 2
- 6- Charging case
- 7- Charging port (USB-C)

BUDS PRO

HOW TO TURN ON AND PAIR THE UNIQ BUDS PRO WITH YOUR DEVICE

STEP 1

Take out the UNIQ Buds Pro from the charging case carefully. Once out, you will hear the sound "Power On" and the two buds flash blue lights quickly.

If the buds don't turn on, please press and hold the touch area for 3 seconds.

STEP 2

Turn on the bluethooth on your device and look for UNIQ Buds Pro. Once you see the correct name in the list click to connect. It will take two secons to connect.

STEP 3

After pairing for the first time, UNIQ Buds Pro will automatically connect with your device. This should happend after you take the buds out of the case.

After being taken out from the charging case, the earphones will be paired automatically. If not, please follow the steps above.

PAIRING



HOW TO USE THE UNIQ BUDS PRO

VOICE ASSISTANT

Touch the left or right earphone three times gently to activate the voice assistant.

This function works with some voice assistant

PHONE CALLS

Answering a call

Touch the left of right bud once.

Hanging up
Touch the left of right bud twice.

Rejecting a call
Press the left or right bud for 2
secs.

LISTNING TO MUSIC

Play/Pause: Toucht he left or right bud twice.

Next song: Press and hold the touch area of right bud for 2 seconds.

Previous song: Press and hold the touch area of left bud for 2 seconds.

Volume up/down: Touch the right or left bud once

Put the earphones into the charging case and the earphone will display a red light while charging.

Please use the usb-c cable included to charge your UNIQ Buds Pro.

CHARGER



SPECIAL INSTRUCTIONS

RESETTING THE BUDS

Delete the bluetooth name which you got connected before from your phone.

Touch the left and right earphones for 5 times respectively. You will see red and blue light flash for 2 seconds at the same time. The earphones will turn on. At the meantime, the earphones are waiting for pairing. Within 10 minutes, it will finish connecting and the earphones will flash blue light.

SPECIAL CASES

Apple iPhones and some Android phones support volume control, but for some Android phones, you can only adjust the volume of the earphone.

When you adjust the volume of the earphones, you are also adjusting the volume of your phone.

Do not touch the touch area while holding the earphones.

PRECUATIONS

Try to listen at low volume. Listening at high volume for an extedn period may result in permanent damage to your hearing.

Keep your earphones and accessories out of reach of children. Children should use the earphones under the supervision of adult.

Use and store the buds between -15 and +50 degrees celius. Don't charge where temperature is below 0 degree C.

Do not expose the earphone to water, moist, dust and long periods of direct sun light.

To avoid damaging your UNIQ Buds Pro, do not disassemble or tamper with them. And do not insert any material into them.





PROMPTS AND INDICATORS

VOICE PROMPTS

Power on
Power off
Clear all pairings
Battery low
Pairing
Pairing success
Disconnected
Volume maximum

Volume minimum

" power on"

" power off"

" power off"

" battery low"

" pairing"

" connected"

" disconnected"

" DuDu"

" DuDu"

BUDS INDICATOR

"Red and blue lights" No pairing Paired buds "Blue light" "Lights off" Paired device "Red and blue (1sec)" Power on Power off "Lights off" "Lights off" Play "Lights off" Pause Standby "Lights off" Incoming call "Blue light every 3 sec" Calling "Lights off" "Red light on" Charging "Lights off" Fully charged

CHARGING CASE

Charging When charging, the

indicator light will gradually

become bright or dim.

Red light 5-35% charged Yellow 35-70% charged

Green 70-100% charged

Full Green light will turn off after 8

seconds

Shortage While 5% battery, the red light

will flash quickly for

4 seconds and then light off.

When the charging case is charged or connected with the cable to a charger, the buds will starting charging one you put them in the charging case.

INDICATORS

TECHNICAL



- 1. Premium TWS Earbuds with built-in microphone
- 2. Fashionable Design Earbuds and Charging Case
- 3. Clear sound and deep bass
- 4. Ergonomic design for an ultimate wearing experience
- 5. Bluetooth version: 5.0
- 6. Bluetooth range: up to 10 meters
- 7. Earphone charging time: 1.5 hours
- 8. Charging box charging time: 2 hours
- 9. Charging case: 500 mAh
- 10. Talk time: 5 hours
- 11. Music time: 5 hours
- 12. Stand-by: 50 hours
- 13. Charging Port: USB Type-C

Model UNIQ Buds Pro EAN 8719273160886

visit:

www.uniqaccessory.com mail to:

sales@uniqaccessory.com