



HBM
Machines

CHARGE FOR 12 HOURS BEFORE USING AND CHARGE AFTER EVERY USE.
DO NOT LET CHARGE FALL INTO RED AREA ON VOLTMETER CHECK BY
PRESSING RED BUTTON NEEDLE SHOULD STAY IN GREEN OR YELLOW AREA.

HBM
Machines

9910

JUMP START

RECHARGEABLE 12V 60AH BATTERY JUMPSTART BATTERY CHARGER

1. ALWAYS USE WITH OFF-ROAD VEHICLES CARLS CONNECTIONS
2. DO NOT PULL ON THE CABLES OR THE ALLIGATOR CLIP
3. DO NOT USE IN A BATTERY ROOM OR IN A BATTERY VEHICLE
4. ALWAYS USE THE RED CABLE TO THE POSITIVE BATTERY TERMINAL FIRST
5. ALWAYS USE THE BLACK CABLE TO THE NEGATIVE BATTERY TERMINAL SECOND
6. AFTER OPERATION, ALWAYS CHECK THE BATTERY VOLTAGE
7. ALWAYS USE THE ALLIGATOR CLIP TO THE POSITIVE BATTERY TERMINAL
8. ALWAYS USE THE ALLIGATOR CLIP TO THE NEGATIVE BATTERY TERMINAL
9. ALWAYS USE THE ALLIGATOR CLIP TO THE POSITIVE BATTERY TERMINAL
10. ALWAYS USE THE ALLIGATOR CLIP TO THE NEGATIVE BATTERY TERMINAL

CE