DUAL MIKE WIRELESS WITH CBTALK APP

Download the CBTalk APP Android/iOs

PTT CBTALK
Push and talk into CBTalk

CHANGE A CHANNEL ON CBTALK

Channel up

Channel down

LED

Turning ON:
Blue led 3 sec.

Turning OFF:
Red led 3 sec.

Pairing:
Red and blue leds alternated

Pairing with Smartphone:
Blue led blinking 3 times

Smartphone's pairing not successful: red led blinking 3 times

Full charge:
Blue led blinks once

While charging:
Red led blinks once

LIGHT RING

Default color:
Steady blue (it will be set through the CBTalk APP)

Incoming call:
Steady white

Low battery:
blinking red

**PTT pressed:**
Steady yellow

BLUETOOTH MICROPHONE

DUALMIKE

(((WIRELESS)))

QUICK GUIDE

EN

DUALMIKE WIRELESS OVERVIEW

1. Volume -
2. Led
3. Volume + (Power Off - 3 sec.)
4. Emergency key (or customizable)
5. Channel up; Channel down (CBTalk)
6. Speaker
7. USB charging port/FW upgrade port
8. Light ring
9. Secondary PTT
10. PTT CBTalk (Power On - 3 sec.)
11. DUAL MIKE WIRELESS is supplied with a metallic plate very useful for magnetic fixing of the microphone and wireless recharge. To use it remove the plastic support fixed with a screw*.

RECHARGE

With USB cable (included)

220V

WIRELESS RECHARGE
Through DK-DUAL, optional Docking Station
(The plastic support must be removed, see point 11*)

POWER ON

3 sec.

Power On

Led steady blue 3 sec.

POWER OFF

3 sec.

Power Off

Led steady red 3 sec.

PAIRING WITH SMARTPHONES

3 sec. *PRESS TOGETHER PTT CBTALK and VOL+*

Device A
DualMike
Device B

STEP 1

Pairing

Red and blue leds alternately blink

STEP 2

Telephone connected

Blue led blinks 3 times

PAIRING WITH OTHER BLUETOOTH DEVICES

3 sec. *PRESS TOGETHER secondary PTT and VOL+*

STEP 1

Pairing

Red and blue leds alternately blink

STEP 2

Bluetooth connected

Blue led blinks 3 times

HAND-FREE PHONE CALLS

3 sec.

To answer/to end a call

White light ring

To reject an incoming call

White light ring

3 sec.

To make a voice dial

AUDIO VOLUME

VOL-   VOL+

Bop (max vol. Beep)