

!

**Ladies and Gentlemen, thank you for purchasing our product!**

Before using, please read the following instructions for the proper use of the product. Please keep this manual for the future and to comply with its recommendations, because failure to do so may endanger life or health.



**Specification**

- White color
- Material: ABS lampholder, PC diffuser.
- Shades of light:
  - cool white 4500K
  - 8000K daylight
  - warm white 3000K
- Intensity levels: 10
- Total number of modes: 30
- Cable length: 5.2 m
- Bulb dimensions (width / height): 5/5 cm
- Weight: 0.22 kg
- Power: The maximum power of a single lamp is 0.8W

**Installation instructions:**

- Clean the place where you want to stick the lamps. The surface should be dry, clean, free from rust, grease, dust and other contamination.
- In each place of the bulb installation, pay attention to the spacing of the lamps up to 33 cm, minimum distance about 15 cm.
- There is double-sided adhesive tape on the bottom of the product. Tear off the foil and then attach to the first lamp. Press down (at least 30 seconds) to make the glue stick better.
- When using the lamps, you can adjust the hues and brightness with the buttons.

1. On / off switch
2. Brightness setting (+)
3. Brightness setting (-)
4. Color adjustment



**Instructions for use**

- The LED lamps in the package should not be connected to the power supply.
- Before connecting, make sure that all sockets have LED diodes.
- Lamps have non-replaceable LEDs.
- It is forbidden to use the lamps if any part is damaged. In the case of a damaged cable, it is forbidden to make any repairs.
- When performing decorative work, disconnect the lamps from the power supply.
- Do not place lamps in places where the cord or bulbs may be damaged.
- Electrical connection with other lamps is forbidden.
- The product is intended only for lighting decoration; it is not suitable for lighting home rooms to improve their visibility.

**ATTENTION**

*PRODUCT INTENDED FOR USE INDOOR.*

**Information for the consumer about the treatment of waste electrical equipment and electronic:**



Waste electrical and electronic equipment may not be disposed of with other household waste. Such equipment should be collected selectively, which is indicated by the attached marking - a crossed-out wheeled waste container.

Failure to comply with the above rule may result in hazardous waste for the environment and human health due to the incorrect presence of hazardous components in the equipment, such as electrical wiring, plastic, circuit breakers, etc., if they are not properly disposed of. To avoid the above hazard, these components should be collected and properly processed by specialized companies. Do not disassemble the used equipment yourself.

Used electrical and electronic equipment can be returned free of charge to the store where it was purchased. Then it is forwarded to a specialized organization dealing with processing, recovery, including recycling and neutralization of hazardous components. Households play an important role in contributing to reuse and recovery, including the recycling of used equipment. This is done in particular through active participation in the waste equipment collection system

