

WITTS

GEBRUIKSAANWIJZING

Ultrasone dierenverjager



Neem de gebruiksaanwijzing goed door om schade aan uw nieuwe product te voorkomen

1 Over WITTS

Bedankt voor het kiezen van WITTS! Lees voor gebruik de gebruiksaanwijzing aandachtig door om eventuele beschadigingen en defecten te voorkomen. Volg altijd deze instructies voor veilig gebruik. Als u vragen heeft over het product of problemen ondervindt, kunt u gemakkelijk contact met ons opnemen via de bestelpagina van bol.com

2 Product profiel


Dit product is een ultrasone dierenverjager, dat bevestigd dient te worden in de tuin of elke andere mogelijk plek buitenshuis waar overlast en/ of vervuiling is van dieren.

Door middel van de ultrasone frequentie die het product uitzendt worden dieren afgeschrikt. Het product laadt op middels zonne-energie, en is ook te herladen door gebruik te maken van de bijgeleverde oplaadkabel.



3 Verpakkingsinhoud

1x Gebruiksaanwijzing
1x Ultrasone dierenverjager
1x Oplaadkabel

4 Product onderdelen



- ① Ophanggaatje
- ② Zonnepaneel
- ③ Ultrasonische speaker
- ④ Bewegingssensor
- ⑤ LED lampje
- ⑥ Frequentieknop
- ⑦ Gevoeligheidsknop
- ⑧ Ingangspunt grondstuk
- ⑨ Grondstuk
- ⑩ Koppelpunt grondstukken



- ① Batterij klep
- ② Zonnepaneel
- ③ USB ingangspunt

5 Belangrijke veiligheidsinformatie

- Bevestig de verjager niet op plekken waar baby's en kleine kinderen spelen.
- Het product is geen speelgoed; houd uit de buurt van kinderen en gebruik pas na het lezen van de gebruiksinstructies.
- Mensen kunnen lage frequenties van het product horen; plaats dus niet te dicht op plekken waar mensen wonen.

6 Gebruiksaanwijzingen

1. Controleer of de ingebouwde oplaadbare batterijen goed zijn bevestigd in het batterij vak.
2. Verwijder de transparante bescherming op het zonnepaneel. Plaats vervolgens de verjager in de richting waar de dieren vandaan komen.
3. Zorg dat de verjager op een plek staat die overdag genoeg zonlicht vangt.
4. Bij het plaatsen van de verjager in de grond, doe dit met beleid. Zorg dat het grondstuk minstens 12 centimeter boven de grond uitkomt.
5. Het product heeft een ophanghaak zodat het gemakkelijk aan de muur gehangen kan worden.
6. Het product kan ook opgeladen worden aan de hand van de bijgeleverde oplaadkabel.

7 Specificaties

- Energietoevoer: 3 oplaadbare batterijen die opladen middels zonne-energie of via de bijgeleverde USB-oplader (5V/500mA)
- Infrarood sensor hoek: 110 graden
- Frequentie: 13,5 KHZ. - 45.5KHZ.
- Bereik: tot 10 meter, afhankelijk van de grootte van het dier.

8 Instellingen

- Gevoeligheidsknop (links): verstel de gevoeligheid van de bewegingssensor. Draai de knop met de klok mee om de gevoeligheid te verhogen. De hoogste stand zorgt ervoor dat zelfs kleine dieren met kleine bewegingen worden gedetecteerd.
- Frequentieknop (rechts): verstel de frequentiehoogte. Draai de knop met de klok mee om de frequentie te verhogen. Er zijn verschillende frequentieniveaus:

0: Uit

1: 13.5kHz-19.5kHz, voor dieren zoals ratten, honden, vossen en marters

2: 19.5 kHz-24.5 kHz, voor dieren zoals katten, wasberen en dassen.

3: 24.5 kHz-45.5 kHz, voor dieren zoals vleermuizen en vogels.

4: LED lamp als extra hulpmiddel voor het verjagen van dieren.

5: Variabele frequentie, wisselend tussen de eerste en vierde frequentie elke 2 seconden.

9 Onderhoud

- Om het apparaat schoon te maken, gebruik een zachte doek, vochtig gemaakt met milde zeep en water. Gebruik geen hardnekkige chemicaliën of ander ruw schoonmaakmiddel.
- Als de oplaadbare batterijen langdurig (1 maand) niet worden gebruikt, kan de deze leeg raken. Het wordt in dit geval geadviseerd om het apparaat volledig op te laden middels de USB-lader.
- Als oude baterijen snel opladen kan dit betekenen dat ze aan vervanging toe zijn.
- Na het verwijderen van de oude batterijen, zorg er dan voor dat deze afgeleverd worden op de daarvoor bestemde inleverpunten binnen uw gemeente.

10 Service en garantie

Indien u service of informatie nodig heeft omtrent uw product, kunt u gemakkelijk contact opnemen via de bestelpagina van bol.com

WITTS verleent 1 jaar garantie op alle producten. De klant dient echter wel een aankoopbewijs te tonen en de garantie dient binnen een periode van 1 jaar na de aankoop geldend worden gemaakt.

Let op: de garantie geldt niet in de volgende gevallen:

- schade veroorzaakt door onjuist gebruik of reparatie;
- voor aan slijtage onderhevige onderdelen;
- voor gebreken waarvan de klant bij aankoop op de hoogte was;
- bij defecten door eigen schuld van de klant;
- bij schade door derden.

11 Disclaimer

Veranderingen onder voorbehoud; specificaties kunnen veranderen zonder opgaaf van reden.

12 Bedrijfsgegevens

SR Products - Partner van bol.com
Afdeling WITTS
Weerdsingel Westzijde 53
3513 BE Utrecht
Nederland
info@srproducts.eu

WITTS

USER MANUAL

Ultrasonic animal repellent



Please read the instructions attentively before use, to prevent
damage on your new product

1 About WITTS

Thank you for choosing WITTS! To ensure proper and safe functioning of the product, please read this manual attentively. Make sure to always follow these instructions for safe usage. If you have any questions about the product, or experience any problems, please contact us via the order page of bol.com

2 Product profile


This product is an ultrasonic animal repellent. The product is ought to be installed in the garden or any other outdoor place where you experience any damage or soiling caused by animals.

The animals will be put off by the ultrasonic frequency send out by the repellent. The product will charge through solar power, and can also by charged by using the additonal charging cable.



3 Packaging content

1x User manual
1x Ultrasonic animal repellent
1x Charging cable

4 Product onderdelen



- ① Hanging loop
- ② Solar panel
- ③ Ultrasonic speaker
- ④ Motion sensor
- ⑤ LED light
- ⑥ Frequency switch
- ⑦ Sensitivity switch
- ⑧ Entry point plot
- ⑨ Plot
- ⑩ Mount point plots



- ① Battery cover
- ② Solar panel
- ③ USB input point

5 Important safety information

- Do not mount the repellent in a place where baby's or small children play.
- This product is not a toy; keep it away from children and do not use before reading the user manual attentively.
- People can hear low frequencies of the product; do not mount nearby a place where people live.

6 User instructions

1. Check if the build in batteries are attached firmly in the battery compartment.
2. Remove the transparent protection on the solar panel. Place the repellent in the direction where the animals come from.
3. Make sure the repellent is mounted in a place where it catches enough sun light during the day.
4. When mounting the repellent; do this with caution. Make sure the plot sticks out above the ground for at least 12 centimeters.
5. The product comes with a hanging loop, so it can be mounted on the wall easily.
6. The product can also be charged by using the additional 5V DC charging cable.

7 Specifications

- Energy supply: 3 build in rechargeable batteries, which are charged through solar energy or through the additional charging cable (5V/500mA).
- Infrared sensor angle: 110 degrees
- Frequency: 13,5 KHZ. - 45.5KHz.
- Reach: up to 10 meters, depending on the size of the animal.

8 Settings

- Sensitivity switch (left): adjust the sensitivity of the motion sensor. Rotate the switch clockwise to increase sensitivity. The highest sensitivity level will provide detection of even small animals with small movements.
- Frequency switch (right): adjust the frequency level. Rotate the switch clockwise to increase the frequency. There are different frequency levels:

0: Off

1: 13.5kHz-19.5kHz, used for animals such as; rats, dogs foxes and martens.

2: 19.5 kHz-24.5 kHz, used for animals such as; cats, racoons and badgers.

3: 24.5 kHz-45.5 kHz, for animals such as; bats and birds.

4: LED light used for extra support in repelling animals.

5: Variable frequency, switching between level one and four every 2 seconds..

9 Maintenance

- To clean the product, use a soft cloth, moistened with mild soap and water. Do not use chemicals or any other rough detergent.
- If the rechargeable batteries are not used over a longer period (1 month), they can be depleted. In this case we advise to recharge the batteries by using the additional charging cable to completely recharge the product.
- If old batteries recharge quickly, this could be a sign that the batteries need to be replaced.
- After removing the old batteries, make sure that they are delivered to an appropriate collection point within your township.

10 Service and warranty

If you need any service or information regarding your product, you can easily contact us via the order page of bol.com.

WITTS provides a 1 year warranty on its products. To obtain service during the warranty period, a proof of purchase is required. Product defects have to be reported within 1 year from the date of purchase.

Note: this warranty does not cover:

- Damage caused by misuse or incorrect repair;
- Parts subject to wear;
- Defects that the customer was aware of during the time of purchase;
- Damages or defects caused by customer neglect;
- Damages or defects caused by third parties.

11 Disclaimer

Changes reserved; specifications are subject to change without grounds for doing so.

12 Company information

SR Products – Partner of bol.com
Department WITTS
Weerdsingel Westzijde 53
3513 BE Utrecht
Nederland
info@srproducts.eu