



WARNING

Always disconnect the power supply before installation, maintenance or inspection.
Always install and use the light strictly according to the instructions.
All the dimensions in mm.
It will be voided warranty of product in light failure.



On/Off
22,000



RoHS



1
50 mA

CR3

PF
>0.5

≥80

IP
20

