

TITAN

BLUETOOTH WIRELESS SPORT HEADPHONES

user manual



Congratulations on purchasing the new TITAN wireless earphone. Your earphone allows for hands-free use on the go. It includes V5.0 echo elimination technology that provides superior sound quality. For best results, read this user manual in full before you use the product.

Product Overview



Power on	Long press the MFB for 3 seconds
Power off	Long press the MFB for 3 seconds
Pairing mode	Long press the MFB for 8 seconds
Answer call	Short press the MFB one time
Cancel/end call	Short press the MFB one time
Reject call	Long press the MFB for 1 second
Last number redial	Double press the MFB
Mic mute switch	Press +- simultaneously
Transfer audio	Long press the MFB for 1 second
Pause/play	Short press the MFB
vol-/vol+	Short press vol-/vol+
Previous/next song	Long press vol-/vol+ for 3 seconds

1

How to connect

1. Keep your Bluetooth device within 1 meter of your wireless earphone when pairing.
2. Enter pairing mode as follows: First, ensure your TITAN is off. Next, press and hold the MFB for approximately eight seconds. You will know that the device has entered pairing mode when the red and blue LEDs flash rapidly.
3. Using your Bluetooth device, scan/search for available Bluetooth devices. Select TITAN from the list of devices shown.
4. If prompted for a password or PIN, enter the following: 0000
5. Some cell phone models can connect automatically and others will provide a prompt. If prompted by your cell phone to connect, select 'Yes'.
6. Once a connection has been established successfully, the blue LED on the headset flashes twice every four seconds.

Multi-pairing

1. Start by long pressing the MFB for three seconds to turn the wireless earphone off. Next, long press the MFB for about eight seconds, until the red and blue LEDs on the earphone flash repeatedly. This indicates entry to the search and pairing state.
2. Turn on the bluetooth of mobile phone #1 and search for TITAN, then click to complete the connection.
3. Turn off mobile phone #1's Bluetooth. Then turn off the earphone by long pressing the MFB until the red LED turns on.

2

4. Long press the MFB for three seconds to turn it on again. Then long press the MFB for eight seconds, until you see the red and blue LEDs on the earphone flash repeatedly again, indicating entry to the search and pairing state.
5. Turn on the Bluetooth function of mobile phone #2. Search for TITAN and click to complete the connection.
6. Turn on mobile phone #1's Bluetooth function and find the connected wireless earphone. Click to complete the connection.

Keep your wireless earphone in close proximity to your cell phone. The TITAN works much better if it has a clear line of sight to your cell phone. Assuming there are no obstacles between your cell phone and the TITAN, it has a range of about 10 meters. Beyond this distance, the connection may become less reliable and sound quality may deteriorate.

Reconnect the headset

1. If the connection is lost, your TITAN will attempt to reconnect automatically.
2. If your wireless earphone is not able to reconnect automatically, press the MFB once or use your cell phone's Bluetooth settings to reconnect manually.

3

Specifications

Bluetooth version: V5.0+EDR QCC3034 Aptx-HD
 Bluetooth profiles: A2DP, AVRCP, HFP, HSP, SPP, DID, HID, PXP, FMP,BAS
 Frequency range: 2.4-2.483 GHz
 Operation range: 15 meters
 Working time: 10-12 hours
 Standby time: about 240 hours
 Charging time: about 2 hours
 Size: 40*24*32 mm
 Built-in rechargeable 100 mAH
 Lithium-ion polymer battery

Charging

Your TITAN comes with a built-in rechargeable battery. Before using the device for the first time, it is recommended to charge the battery fully.

1. Connect TITAN to your USB charger.
 - Red LED indicates the device is charging
 - Blue LED indicates the device is fully charged
2. It takes 1.5-2 hours to charge the battery fully.
3. Please note the input power should be no more than DCSV/1A, to avoid potential damage to the earphone.

4

Restore to factory settings

Long press the MFB button for about three seconds while charging. The red and blue LEDs will flash three times to indicate that factory settings have been restored.

Common problems and solutions

1. Cell phone does not detect the TITAN

- Solutions:
- 1) Confirm that the wireless earphone is turned on and in pairing mode. If the blue and red LEDs are flashing alternately, the earphone is in pairing mode.
 - 2) If the wireless earphone is turned on but still can't be found on your Bluetooth device, restart both the cell phone and the wireless earphone and then try again.

2. After connecting the wireless earphone with your mobile phone, you experience disconnections or low sound quality.

- Solutions:
- 1) This wireless earphone may have low battery. Recharge the device as needed.
 - 2) There may be an obstacle between your cell phone and the wireless earphone. Ensure this is not the case. You should be aware that your hand may obstruct communication if you are holding it against the TITAN. Make sure the line of communication is clear of any obstruction between these two devices.
 - 3) Your wireless earphone may be out of range. Try moving it closer to your cell phone for best results.

5

3. The wireless earphone has connected successfully, but you can't listen to music.

Solutions:

- 1) Some cell phones do not have a complete Bluetooth function and stereo Bluetooth module that are required to listen to music. Please test whether this is the case by connecting your wireless earphone with another cell phone. If you can listen to music through the other cell phone, the wireless earphone is functioning as it should.
- 2) Check your Bluetooth settings of handsfree mode.

4. How to use the wireless earphone to listen to music or chat on computer?

If your computer has a Bluetooth function, simply open it and search for the wireless earphone. If your computer does not have a Bluetooth function, then you will need a wireless adapter in order to connect your computer to the TITAN. We recommend IVT wireless adapters.

5. What's the Bluetooth pairing password?

The Bluetooth pairing password is 0000. Only a very small proportion of cell phones require manual password entry. Most cell phones enter this password automatically.

6

6. The red light is not on when charging

Solutions:

If the Bluetooth earphone has not been used for a long time, it may need to be charged. Try charging the TITAN for 30 minutes. The red light should come on again.

Warranty

We guarantee every product has undergone rigorous tests prior to shipping. We are so confident in the quality of our products that we offer a one year warranty from the date of purchase.

Note: this TITAN conforms to IPX7 waterproof standard:

Suitable	<ul style="list-style-type: none"> * Splashes * Rain or Snow * Showering * Incidental exposure to water of up to 1 meter for up to 30 minutes
Unsuitable	<ul style="list-style-type: none"> * Swimming * Diving into water * Snorkeling or Scuba Diving * High-speed watersports

7

Contact Us

For any inquiries, issues or comments concerning our products, please send a message via the website you bought this product on, and we will respond as soon as possible

8