

Instructies interactieve (bewegende) vis

INSTRUCTIONS

- ◆ It will wag its tail when you turn on the switch and slap its belly;
- ◆ The charger no more than 5V, such as mobile phone charger or USB port of computer, the red light will be on when charging and off when finished, charging time generally takes 70 minutes;
- ◆ Take out the plastic parts in the belly and clean plush shell;
- ◆ The bag contains catnip. Its smell can make the cat happy.