


**RUNNER II R1 A/B RUNNER II R1 C/D**  
**RUNNER II R2 A/B RUNNER II R2 C/D**



WWW.AGURI.EU




LIT Pritvirtinimo instrukcijos  
PL Instrukcja montażu  
CZ Návod na montáž  
SK Návod na montáž  
SLO Navodila za pritrjevanje  
HR Uputa za sastavljanje  
HU A felszerelés módja  
GR Οδηγίες συναρμολόγησης  
UA Інструкція з монтажу  
BY Інструкцыя па мантажы  
RO Instructiuni de montare  
TK Uydurma talimat  
N Monteringsveiledning




I Istruzioni per il montaggio  
GB Fitting instructions  
F Instructions de montage  
D Montageanleitung  
E Instrucciones de montaje  
NL Montage-instructies  
DK Monteringsinstruktion  
FIN Asennusohje  
S Monteringsanvisning  
RU Инструкция по установке  
PT Instruções de Montagem  
EST Paigaldusjuhend  
LAT Stiprināšanas instrukcija





## RUNNER A/B




## RUNNER C/D









1 - 2 - 3 - 4




1 - 2 - 3 - 4



1 - 2 - 3 - 4




1 - 2 - 3 - 4



CHECK





### OPTIONAL ACCESSORIES

