TECHNICAL DATA

C E ₃₁₂	KE		Outdoor stove				PIN 1312BR4806			
Gas category	I ₃₊ (28-30/37)									
Gas type	Butane					Propane				
Use pressure	28-30 mbar					37 mbar				
Item code	104980	1049	981	104982			104983			
Number of burners	1	2		3			4			
Type of burner	Medium	Medium	Large	Small	Medium	Large	Small	Medium	Medium	Large
Dimension of injectors (mm)	0.53	0.53	0.59	0.47	0.53	0.59	0.47	0.53	0.53	0.59
Consumption (g/h)	88	88	102	62	88	102	62	88	88	102
Rated capacity (kW)	1.2	1.2	1.4	0.85	1.2	1.4	0.85	1.2	1.2	1.4



SAFETY WARNINGS

- Only use this appliance outdoor or possibly in properly-aerated premises, at safety distance from any heat source, flame
 or spark and away from accumulated dirt or flammable material.
- Place the stove on ground or floor, anyway always horizontally. Never place the stove on surfaces made of wood, plastic
 or other flammable materials.
- Any change to the appliance can be dangerous. Never modify your stove and do not absolutely disassemble the appliance
 and its components. Only qualified and specialized personnel must repair the appliance.
- 4. Parts, which have been sealed by the manufacturer, should not be altered by the user.
- Check no damage has occurred to the appliance. Do not operate the appliance if damaged.
- Only use this stove for food cooking.
- Never use the appliance with damaged or worn seals.
- 8. Never use the appliance if leaking, damaged or badly operating.