

OneMelon[®]



DROPS

User manual

NL | EN

NL

Gefeliciteerd

Ineens valt alles op z'n plek. Het voelt goed, het klinkt goed en het past goed. Een langdurige vriendschap die je meeneemt naar mooie momenten. De toekomst klinkt je als muziek in de oren. Producties klinken zoals ze bedoeld zijn. Diep en gebalanceerd. Je bent onderweg en luistert naar je favoriete podcast, luisterboek en muziek. Je bent verbonden met de mensen die je wilt spreken. Ook onderweg. Geen last van omgevingsgeluid: jij niet en je gesprekspartner niet. Je hebt je handen vrij. Je bent de trotse eigenaar van de

OneMelon Drops



EN

Congratulations

Suddenly everything falls into place. It feels good, it sounds good and it fits perfectly. A long-lasting friendship that takes you to beautiful moments. The future sounds like music to your ears. Deep and balanced. You're on the go and listening to your favorite podcast, audio book or song. You are connected to the people you want to talk to. Wherever you are. Ambient noise is no longer a problem: not for you nor for the person you call with. Your hands are free. You are the proud owner of the **OneMelon Drops.**





NL | EN

Controls Bediening






NL

**Vragen +
antwoorden**



EN

FAQ's



Connecting first time
Eerste keer verbinden




When off
hold 5 sec.



(L)




(R)





Music mode — Game mode — Sleep mode



ANC | Transparency mode





2x



(L)

or



(R)



(L)



(R)



2 sec



Ⓕ




Ⓖ



2x + hold





For best sound experience

choose the size (small, medium, large) silicone eartips that fit tightly in your ear. Make sure no sound escapes.



Ⓛ or Ⓜ





Eén oordop gaat niet aan

Tijdens het indoen is één oordopje uitgegaan en je gebruikt nu de mono-modus. Hou het oordopje dat geen geluid geeft ingedrukt tot hij weer aangaat.

Ik hoor mezelf niet tijdens het bellen

Maak gebruik van de transparency mode tijdens het bellen. Druk tijdens het bellen 4 keer achter elkaar op de oordop om de transparency mode te activeren.

De touch bediening reageert niet

Je hebt de sleep mode aangezet. In die modus reageert de touch bediening niet. Druk 3 keer op je oordopje om weer naar music mode te switchen.



Ik kan de OneMelon Drops niet vinden tussen bluetoothapparaten

De OneMelon Drops verbinden altijd met het laatst verbonden device. Zijn ze niet al met je laptop, tablet of andere telefoon verbonden? Zo niet: doe een reset en zorg dat je bluetooth aan staat.

Hoe reset ik de oordopjes?

Haal de oordopjes uit het doosje en zorg dat ze niet verbonden zijn met een telefoon, tablet of laptop. Tik 2 keer op de oordop (lampje gaat knipperen). Herhaal met de andere oordop.



Waarom verbinden de OneMelon Drops niet meer automatisch met m'n telefoon?

Meestal heb je dan ongewenst een factory reset toegepast. Dat doe je door 2 keer te tikken op je oordop als ze niet verbonden zijn met een device. Verbind opnieuw en daarna zullen ze weer automatisch verbinden met je device.

Hoe werkt de sleep mode

Druk 3 keer op je oordopje om de sleep mode te activeren. Vanaf dat moment wordt de touch bediening gedeactiveerd. Je kunt ongestoord in slaap vallen.



De oordopjes disconnecten niet in de oplaadcase

Dan is de oplaadcase leeg. De OneMelon Drops krijgen een seintje om te disconnecten als ze in de oplaadcase zitten met het klepje dicht. Als de case leeg is, lukt het de oplaadcase soms niet om de oordopjes te disconnecten.

Weinig bass en lage tonen. Waarom?

Kies voor de maat eartips die precies goed afsluit in je oor. Alleen dan hoor je een mooi gebalanceerd geluid met lage, midden en hoge tonen. Sluiten de oortjes niet af? Dan is de eerste toon die sneuvelt, de lage toon. De bass. Kies dus de maat die goed in je oor afsluit.

**One earbud does not turn on**

You accidentally switched off one earbud when taking it out of the case. Now its on mono mode. Press and hold the earbud that is off until it turns on again.

I cannot hear my voice while calling

Switch to transparency mode during your call. Press 4 times in a row on the touch control to activate the transparency mode.

The touch control does not respond

You might have enabled sleep mode. In that mode, the touch controls do not respond. Press your earbud 3 times to switch back to music mode.



I can't find the OneMelon Drops in the bluetooth setting

The OneMelon Drops always connect to the last connected device. Aren't they already connected to your laptop, tablet or other phone? If so: turn of bluetooth of the other device. If not: do a reset.

How do I reset the earbuds?

Take the earbuds out of the charging case and make sure they are not connected to a phone, tablet or laptop. Tap the earbud 2 times (light will flash). Repeat with the other earbud. Reconnect the earbuds to your device.



The OneMelon Drops do not connect automatically to my phone. Before they did. Why?

Usually you have applied a factory reset unintentionally. You do this by tapping your earbuds twice if they are not connected to a device. Connect again in you bluetooth settings and then they will automatically reconnect to your device.

How does the sleeping mode work

Press 3 times on your earbud to activate the sleep mode. From that moment on, the touch controls are deactivated. You can fall asleep undisturbed.



The earbuds do not disconnect in the charging case

Then the charging case is empty. The OneMelon Drops receive a signal to disconnect when they are in the charging case with the lid closed. If the case is empty, the charging case sometimes fails to disconnect the earbuds.

Little bass and low tones. Why?

Choose the size of the eartips that fit tightly in your ear. Only then you will experience a great balanced sound with low, mid and high tones. If the earbuds don't seal well in your ear the first sound to lag is the lower sound: the bass. So choose the size that fits well in your ear.



DROPS

This package contains as little plastic as possible. OneMelon loves our earth. That is why we named every product after a natural phenomenon.

