

Model: DVM-SA30 (Photoelectric Smoke Alarm)
Batch NO.: 202206 Replace By End: 2032.06
Battery Spec.: DC 3V(CR123A)

## WARNING:

• Test weekly. • Battery not replaceable. • Read the user's manual before installing and operating. • Clean by vacuum, cleaning the outside of the unit each month, refer to user's manual. • The red LED will flash every 8 seconds, indicates the smoke alarm is running into the silence(Hush) mode. • An intermittent "chirp" with red LED flashes once every 48 seconds, indicates a low battery, Please replace the smoke alarm.



1116-CPR-132 DoP: RD-380A-H-24-001 EN 14604:2005/AC:2008 Ver: 1.0

41.30 mm

78.00 mm