

Lesenz Mini User Manual



- | | |
|---|---|
| 1 Speaker | 2 Micro USB socket |
| 3 Power Button for:
Answering Calls
Camera Remote Shutter | 4 LED indicator
5 keychain
6 Microphone |

Specifications:

Model	LZ Mini
Power Rating	IW
Transmitting Frequency	150Hz-16KH z
THD	< 1%
S/N	≥90dB ±2
Speaker Parameter	4Ω diameter 30mm
Battery	3.7V/140mAh
Bluetooth Version	V4.2
Product Size	φ 35.6x25.1mm
weight	21g

Charging battery:

- 1 Insert the charging cable into the Micro USB input port, connect the USB plug into a 5V/300mAh USB power terminal. The LED indicator will turn red.
 - 2 After fully charged, the red LED indicator will turn off.
- Note:** When sound becomes less and you hear the warning tone "1 beep", then charge speaker on time.

Bluetooth pairing for music/ phone call/ camera remote shutter

- 1 Turn on the speaker by pressing "@" button for 3 seconds, The speaker will have a voice prompt and a blue indicator will flash.
- 2 Turn on your device and activate the Bluetooth function.
- 3 Search for Bluetooth name "Lesenz Mini" to connect with. The speaker will pair automatically and the speaker will have a voice prompt, the blue indicator will flash. Then, just need to press "@" button to play music when you open your music player or answer the call when the call is coming. Or take a photo when the camera app is opened on your device.

- 4 Turn off the speaker by pressing @+ button for 4 seconds and the speaker will let you hear 2 beeps. When disconnected, the speaker will turn off after 5 minutes

- Note:**
- 1 When it is not possible to take a photo. Under the Android system, please open "Settings": "camera", then set "Volume key" to "Settings": under the IOS system, you just need to refresh the Bluetooth connection
 - 2 When you can't play the music, please refresh the Bluetooth connection.
 - 3 While playing music, short press @+ button will increase the volume

