

playmobil®

6120



**WARNING:**  
**CHOKING HAZARD**

Contains a small ball and small parts.  
Not for children under 3 years.


"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
Belangrijke documenten, bewaar deze zorgvuldig!








1



2







3




4






5





6









7







8






9







10






11







12






13







1




2




3







4



1



2





**1** 2x 30 22 4162, 30 82 3790, 30 22 2742

**2** 30 23 1440, 30 22 4152, 30 08 1440, 30 22 4142

**3** 2x 30 60 3312

**4** 30 66 8180, 30 22 4172, 30 82 6192

**1** 30 51 4432

**2**

30 64 0024

30 21 9283

30 07 4290

30 07 0900

30 82 3680

30 21 1142

30 21 9233

30 21 9243

30 29 5850

30 00 5343

30 02 3410

30 14 7730


2x 30 83 0110, 30 21 1210

30 83 0120

30 83 0130, 30 22 2522

30 11 1500







30 21 9503




30 21 9463




30 51 4462




30 21 9413




30 51 4482



30 21 9473



30 51 4492



30 51 4472






30 21 9443



30 21 9453



30 21 9483



30 05 4720




30 21 9343



30 21 9523



30 82 5113




30 21 9433




30 25 1103



12x 30 28 6150



30 21 9423



30 51 4452



2x 30 21 9383



30 21 9393



30 21 9333



30 21 9353



30 21 9373



30 21 9323



30 21 9403



2x 30 25 1093



2x 30 25 1083



3x 30 21 9493



2x 30 21 9513



30 21936 3



30 23 6120



2x 30 67 1850



2x 30 65 6942



30 60 0390



30 51 4442





30 66 9280



30 66 9290



30 09 7000



30 66 8220



30 09 7020



30 66 1200



30 27 8280



2x 30 20 1200



30 23 5830



30 25 0973



30 26 6630



30 02 1810



30 63 9994



3x 30 21 9313



4x 30 21 9303



3x 30 66 1190



30 80 2950



30 67 6212




30 05 0970



3x 30 22 2812



2x 30 23 6150



30 21 0163



30 09 7150



30 09 3160



30 09 3140



6x 30 20 7863



30 23 4523



30 63 9854



30 05 2890



2x 30 25 7603



30 22 2802



2x 30 25 6350



30 26 8710



30 25 1563



30 62 1053



30 03 1150



30 51 9430



2x 30 22 2792



30 07 5450



17x 30 21 9293



2x 30 25 8710



3x 30 21 9263



7x 30 21 9273

Serviceadressen finden Sie in allen Playmobil-Prospekten  
 Addresses of Customer Service Departments are shown in all Playmobil catalogues  
 L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil  
 Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.  
 Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil  
 Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.  
 pronounce: plāy-mō-bēēl

