

# Multifunctional Steam Brush

- Please push down Control switch on the side of handle and then fold the handle.
- When using for the first time, the blue indicator light flashes. Do not turn on the steam button (to avoid water leakage). When the blue indicator turns red, it can be used only after the heating is completed! (blue and red are used alternately in the later use)
- First use it is normal to appear a little smoke, odor and sounds caused by the internal environmental friendly oil evaporating at high temperature and this phenomenon will disappear over time.
- Just start up or water tank water too little, hear the motor rattle idling sound, because there is air in the suction hose, when the air is discharged or the water tank is full of water, the motor clattering sound will disappear!





Thanks for your purchasing the hand-held steam brush. Before you buy this product, please read the relevant using instructions and precautions in detail. This instruction will help you understand the product better and use it correctly. After you have read the instructions, please keep them carefully. Because of its powerful steam system, the steam brush will allow you to iron clothes conveniently. It can be used in ironing and cleaning for common clothes as well as eliminating the odor on clothes.

# 01 / Notes

---

Steam brush is household appliance, so the following safety precautions must be taken:

- Please keep away from children
- No using for water tank without adding water.
- Keeping your hands dry when using steam brush.
- No accessories shall be installed or removed when the product is in use.
- After using, kindly unplug the power supply with no plug for the wire. It is necessary grasp the plug and pull it out of the socket.

- No using for steam brush facing people, animals or other electrical appliances to avoid harm.
- Do not directly iron clothes which is worn on your body
- To prevent body injury or scalding for commodity surface, kindly do not place steam holes on the floor or surface of other objects during no using for this product.
- Do not install or remove accessories when the product is connected to power supply or under hot status.

## **Disclaimer:**

- When you choose to buy this product, that means you have agreed to the following contents:
  1. Due to the different variety of clothing fabrics and various ways of personal operation, it may cause clothing damage or personal injury.
  2. For any loss caused during using this product shall be undertaken by the parties concerned, and the company shall not be liable.

- Do not put the wire or product into water or any other liquid.
- In order to avoid overload of household power supply, do not use it with other household appliances.
- If steam is emitted from any position of the product (except the normal position on steam panel), this product should not be used.
- Special wire should be applied and it should not touch the high-temperature surface.
- When the steam brush is powered on, kindly do not leave it alone.
- If the power supply is damaged, the accessories should not be removed and replaced by themselves. In order to avoid the risk, it must be replaced by the professional personnel from manufacturer or its maintenance department.
- Don't press or break the steam brush.
- The following persons (including children) are not the target users for this product: persons who are handicapped in physically, sensory or mentally or lacking experience and knowledge unless they are supervised or instructed about the using of this product by those people who are responsible for their safety.
- Ensuring the steam not to touch with other electrical equipment.
- There are many kinds of clothing fabrics. Some fabrics cannot be ironed directly. If you are not sure whether they can be ironed, please test on the same kind of fabrics which are useless before deciding.
- The losses caused by clothes ironing shall be borne by the parties concerned.


## 02 / Contains

---

- Handheld steam brush
- Measuring cup for water injection
- Machine water tank
- Long-haired brush
- Flannelette brush
- Instructions

# 03 Product structure

---



1 Long-haired brush



# 04 / Installation method

---

1. Before accessories installation or removal, it is necessary to ensure that the products are not powered on and there is no steam coming out. At the same time, the users should ensure that accessories to be installed or removed are in a cold state. If the products are still in a hot state, please use heat-insulating gloves (which is needed to be prepared by yourself) for removal.
2. Please select the accessories to be installed/removed.
3. When installing the long-haired brush (as shown in chart 1), the user should put the long-haired brush (position 1) into machine slot and then press the position 2 into machine slot.
4. When removing the long-haired brush, please pull the position 2 out to remove the brush.



Graph 1

# 05 / Water injection method

---

1. Please cut off the power supply and pull out the plug when removing or installing the water tank.
2. Turning the water tank clockwise according to instruction of water tank buckle to remove the water tank (shown in chart 1).
3. Open the nozzle cover and add water to the tank with a measuring cup. Kindly pay attention not to exceed the full limit and re-cover the nozzle cover tightly after filling (as shown in chart 2)
4. Installing the water tank back to its original position according to instruction of water tank buckle. The users should iron the surface of clothes from top to bottom, moving back and forth.

Firstly, please cut off the power supply and unplug the socket. When the water tank should be installed or removed, this action can only be done when the product is cooled.



Graph 1



Graph 2

# 06 / 1. Product instruction

1. When using for the first time, the blue indicator light flashes. Do not turn on the steam button (to avoid water leakage). When the blue indicator turns red, it can be used only after the heating is completed! (In the later use, the blue and red indicator lights can be used normally).
2. When ironing, one hand should straighten the clothes and the other hand should hold the jet switch on machine. The steam panel should be close to the surface of clothes, moving from top to bottom frequently.
3. You can also push down the lock on steam switch and fix the steam switch (graph 2). At this moment, the steam will be injected continuously so that clothes ironing can be conducted with methods described above.
4. If you have encountered clothes that are particularly difficult to iron, put steam panel very close to the clothes folds to spray steam for several seconds and smooth the folds effectively.
5. After using and unplug the socket; pouring out the water in water tank and storing it properly after the machine is cooled.



Graph 2



When using for the first time, the blue indicator light flashes.

Do not turn on the steam button (to avoid water leakage).

When the blue indicator turns red, it can be used only after the heating is completed! (In the later use, the blue and red indicator lights can be used normally).



Graph 1

### 3. Product instruction

---

1. The handles of this machine can be folded during traveling or packed.
2. Firstly, pushing down the switch on handle (graph 1)
3. At the same time, folding the handle downward to proper position (graph 2)
4. When the handle is opened, it is needed to be pulled away in the opposite direction of graph 2.



## 4. Product instruction

---

During traveling or business trip, if larger water tank is needed, external mineral water bottle can be connected as water tank.

1. Firstly, mineral water bottle should be filled with water and installed to the adapter (graph 1)
2. Installing the adapter to machine (graph 2)
3. After installation, the clothes can be ironed with normal operation.



Graph 1

Graph 2

# 07

## Ironing tips

---

- Clothes ironing should be from inside to outside.
- During clothes ironing, touching the clothes gently and iron them from different angles to remove wrinkles. It's important to let the steam brush and clothes touching each other.
- The steam brush cannot remove dirt.
- The steam brush can be used for dry cleaning of most materials (including silk, cotton, nylon, wool and etc.). Please read the material label for relevant clothing carefully to check whether it can be ironed. Some clothing such as leather, artificial leather, velvet and so on cannot be ironed.
- To ensure that your favorite clothes can be ironed, test should be conducted to a small piece of clothes in advance. If it does not cause any damage, you can be rest assured to iron it.

# 08

## Cleaning And Maintenance

---



1. When cleaning this product, please be sure to unplug the power socket.
2. Please cool the machine for 10-15 minutes firstly.
3. Removing the water tank and making it to be empty.
4. Please be assured that both products and accessories are completely cooled when cleaning them.
5. Keeping the product in a safe and dry place.
6. Please use clean tap water, such as filtered water, mineral water or distilled water to extend the service life of product.
7. Do not add liquids other than water such as detergents, chemicals, brine, perfume, dye and etc. to the water tank. Many of above liquids are inflammable objects which can cause body injury easily. The additives may also bring damage or blockage to the steam system of product. Meanwhile, do not add spices to water.

# 09

## Method for removing scale

---

There is a common problem for steam brush that incrustation scales will accumulate in the steam chamber after long-term using of tap water. The reduction for incrustation scales can be achieved to inject filtered water, mineral water or distilled water.

If there is no condition to use pure water, the reduction for incrustation scales can also be achieved with following steps at least once a month.

- Ensuring that the product is powered off and cooled completely.
- Mixing water and vinegar in a ratio of 1:1 to produce 60G liquid.
- Opening the nozzle cover and pouring the liquid into water tank slowly.
- Injecting steam for about 40 minutes continuously and adding water into water tank on time when there is no water.
- Pouring the remained solution into a tank or other container.
- Filling the cup with water and washing it until it smells vinegar-free.



