

- (1).Left button:left button function
- (2).Right button:right button function
- (3).Middle button:middle button function
- (4).Back button: back to previous page
- (5).Forward button: enter to next page
- (6).DPI+: switch to higher DPI value,without loop switch
- (7).DPI-: switch to lower DPI value, without loop switch
- (8).Three bursts:Equivalent to click the left key for 3 times
- (9).Fire key: according the mouse key to adjust the speed rate.
- (10).Combination key: customise Ctrl, Shift, Alt, Win and any of the keyboard buttons to combine button functions(support 3 assemblies farthest,such as Ctrl+A+B)
- (11).Multimedia function: include Play / Pause, Stop, Previous, Next, Volume Up, Volume Down, Mute, Email, Calculator, My computer and Homepage functions.
- (12).Disable the key: to set bottom has no function.
- (13).DPI: DPI+, DPI- and DPI loop
- (14).Locking DPI, from 800-4800 to lock any of the DPI values.
- (15).The return rate of mouse with 125HZ /250HZ /500HZ /1000HZ to choose



3

- (16).The movement speed of mouse:to adjust the movement speed of mouse
- (17).The scroll wheel speed of mouse :to adjust the scroll wheel speed of mouse
- (18).The double-click speed of mouse: to adjust the double-click speed of mouse.
- (19).Export the current configuration:store the content that have been set to your computer.
- (20).Import the configuration file: load the existing documents from the computer.
- (21).Factory reset: Set the mouse to the factory default
- (22).Application: write the settings to mouse

2.Macro definition

Macro management can record any keys of keyboard and the keys reaction time ,number of keys cycles.

- a. Click [create] a new file, such as a, b, c...
- b. Select whether to increase the delay and the times of cycles
- c. Click [start recording]and start recording any keys of keyboard. The keys you recorded will display in the macro edit box(it can only record 16 keys at last)
- d. After the recording, click "stop recording"
- e. To revise the recording content, please make the following changes in the macro options:
 - Choose to insert the event: insert relevant content in the the selected location
 - Delete: Delete the selected content
 - Modify:Modify the delay value and input button again
- f. After recording is completed, just exit the macro recording interface, no need to click the confirmation keys
- g. Execute a macro, such as the mouse button (5) key set to "macro functions", after recording is complete, press the mouse (5) key to play the recorded content

4