

enfant.
Utilisation intérieure.
Conserver cet emballage pour
référence ultérieure

ATTENTION
INFORMATIONS IMPORTANTES A
PROPOS DES PILES

- Les piles non rechargeables ne doivent pas être rechargées;
- Les accumulateurs doivent être chargés uniquement sous le contrôle d'un adulte.
- Les accumulateurs rechargeables doivent être enlevés de la veilleuse avant d'être chargés.
- Les différents types de piles ou accumulateurs ou des piles ou accumulateurs neufs et usagés ne doivent pas être mélangés.
- Les piles ou accumulateurs doivent être mis en place en respectant la polarité.
- Les piles ou accumulateurs usés doivent être enlevés de la veilleuse.
- Les piles ou accumulateurs doivent être enlevés de la veilleuse lorsqu'elles fuient.
- En cas de fuite des piles, évitez de les laisser entrer en contact avec la peau et les yeux.
- Les bornes d'une pile ou d'un accumulateur ne doivent pas être mises en court-circuit.
- Ne pas jeter les piles au feu, cela pourrait causer des explosions ou des fuites.

UK: INSTRUCTION:

1. Open battery door.
2. Insert 3pcs of AA battery with correct polarity (not included).
3. Press the ON/OFF switch once for white light, press again for color flashing.

BATTERIES REPLACEMENT:

Batteries should be replaced by an adult.
Not suitable for children under 3 years old. For indoor use only. Retain this box for future reference.

WARNING

IMPORTANT WARNINGS ABOUT BATTERIES

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Non-rechargeable batteries should not be recharged.
- Batteries should be inserted with correct polarity.
- Batteries should be removed from the toy.
- Batteries should not be short-circuited.
- Rechargeable batteries are to be removed from the toy before being recharged.
- Rechargeable batteries are only to be charged under adult supervision.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries must be removed from the nightlight when they are leaking.
- If the batteries leak, do not let them come in contact with skin and eyes.
- Do not dispose of batteries in fire, batteries may explode or leak.

MINI LAMPE LED LED MINI LAMP



FR : Ne convient pas aux
enfants de moins de 3 ans.
UK : Does not suit to the
children of less than 3 years.

