

- 4 **VOL**
- Press to decrease the speaker volume.
 - Press repeatedly until the volume reaches the minimum to turn it off.
 - While in a menu, press to scroll down.
- 5 **↩**
- While in a menu, press to return to the previous menu.
- 6 **Speaker**
- Press to enter the menu.
 - While in a menu, press to choose an item, or save a setting.
- 10 **On/Off**
- **Press and hold** to power on, the screen turns on.
 - **Press and hold** again to power off, the screen turns off.
 - While in a menu, press to return to idle screen.
- 11 **Talk**
- **Press and hold** to talk to the baby unit.
- 12 **Power jack**
- 13 **Belt clip**
- 14 **Battery compartment cover**

- detected from the baby unit.
- Mute**
- Displays when the patient unit speaker volume is turned off.
- Battery status**
- animates when the battery is charging.
 - displays solid when the battery is fully charged.
 - flashes when the battery is charged with AC adaptor, or charging is failed.
 - flashes when the battery is in low level and needs charging.
 - No battery icon displays when there is no battery installed.

- confirmation tone.
- NOTE**
- To enter the **VOX Level** menu of the parent unit, the baby unit must be turned on.
- Sound alert**
- If you turn on the sound alert, the parent unit beeps when the baby unit detects sounds which had triggered the red light of visual sound indicator on the parent unit.
- When the sound alert of the parent unit is turned on, is shown on LCD display. The sound alert is preset to **OFF**.
1. Press when the parent unit is not in use.
 2. Press or to choose **SOUND ALERT**, then press . The screen displays **ON?** or **OFF?**.
 3. Press to confirm your selection. The screen displays **SAVED** and you hear a confirmation tone.

3. Press or to choose your desired volume level, then press . The screen displays **SAVED** and you hear a confirmation tone.
- Night light**
- The baby monitor has the night light for you to sooth and comfort your baby at night. You can turn on or off the night light on the baby unit using the parent unit. You can also turn on or off the night light with the baby unit manually.
- To turn on or off the night light using the parent unit:
1. Press when the parent unit is not in use.
 2. Press again to choose **NIGHT LIGHT**. The screen displays **ON?** or **OFF?**.
 3. Press to confirm your selection. The screen displays **SAVED** and you hear a confirmation tone.

OPERATIONS (CONT'D)

Lullaby

The baby monitor has five lullabies for you to comfort your baby. You can play or stop lullabies on the baby unit by controlling remotely with the parent unit.

1. Press when the parent unit is not in use.
2. Press or to choose **LULLABY**, then press .
3. Press or to choose a lullaby, or choose **PLAY ALL**, then press . The screen displays **PLAY** or **STOP**.
4. Press to confirm your selection. The screen displays **SAVED** and you hear a confirmation tone.

NOTES

- If you choose a lullaby, the selected lullaby will be played repeatedly for about 20 minutes.
- If **PLAY ALL** is selected, the five lullabies will be played one after the other, until all of them are played.
- When the lullaby is playing, the parent unit displays the name of the selected lullaby, or **PLAY ALL** on the idle screen.

Temperature

Your baby unit monitors the temperature of your baby's room with its built-in temperature sensor. If the detected temperature is out of the preset temperature range, the parent unit will display an alert message.

Set temperature format:

You can choose to display the temperature in Fahrenheit (°F) or Celsius (°C).

1. Press when the parent unit is not in use.
2. Press or to scroll to **TEMPERATURE**, then press .
3. Press or to choose **FORMAT**, then press . The screen displays **FAHRENHEIT?** or **CELSIUS?**.
4. Press to confirm your selection, The screen displays **SAVED** and you hear a confirmation tone.

Set temperature range:

You can set the desired room temperature alert range. The minimum temperature can be set between 52 °F (10 °C) and 69 °F (20 °C). The maximum temperature can be set between 70 °F (21 °C) and 86 °F (30 °C).

To set minimum temperature

1. Press when the parent unit is not in use.
2. Press or to scroll to **TEMPERATURE**, then press .

3. Press or to choose **MINIMUM**, then press .
4. Press or to choose the desired minimum temperature.
5. Press to confirm your selection, The screen displays **SAVED**. You hear a confirmation tone.

To set maximum temperature

1. Press when the parent unit is not in use.
2. Press or to scroll to **TEMPERATURE**, then press .
3. Press or to choose **MAXIMUM**, then press .
4. Press or to choose the desired maximum temperature.
5. Press to confirm your selection, The screen displays **SAVED**. You hear a confirmation tone.

Set temperature alert tone

You can turn on the temperature alert tone so that the parent unit will emit an alert tone if the detected temperature is out of range.

1. Press when the parent unit is not in use.
2. Press or to scroll to **TEMPERATURE**, then press .
3. Press or to choose **ALERT ON/OFF**, then press . The screen displays **ON?** or **OFF?**.
4. Press to confirm your selection, The screen displays **SAVED**. You hear a confirmation tone.

Set default

Use this feature to restore to the default settings. Restoring the default settings on one parent unit will also reset the shared settings for VOX sensitivity level of the other parent unit.

1. Press when the parent unit is not in use.
 2. Press or to choose **RESET**, then press . The screen displays **CONFIRM?**.
 3. Press to confirm. The screen displays **SAVED**. You hear a confirmation tone.
- OR-**
- Press to exit the menu. The current setting remains unchanged.

CUSTOMER SERVICE AND PRODUCT WARRANTY

vtech

PRODUCT REGISTRATION

Visit www.vtech.co.uk/clubvtech/login to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.

ONE YEAR PRODUCT WARRANTY

Thank you for choosing this quality product from VTech.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe Pic (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe Pic will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorized repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Products returned to VTech Electronics Europe Pic, should be sent to the address shown below and packed carefully to avoid damage in transit. Please do not include batteries or adaptors. Please include details of the fault together with your name and address, contact phone number and/or email address.
8. To keep an online record of your warranty, please register your product online at www.vtech.co.uk/clubvtech

VTech Electronics Europe Pic, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Ireland only. For products purchased outside the UK and Ireland, please contact your local distributor or place of purchase.

IMPORTANT

Please retain this booklet with your sales receipt as proof of the date of purchase.

Customer Service

Please call our Consumer Services Department on 03306 780149 (from UK) or +44 3306 780149 (outside UK) and a service representative will be happy to help you.

GENERAL PRODUCT CARE

- To keep this product working well and looking good, follow these guidelines:
- Avoid placing it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
 - DO NOT expose it to direct sunlight or moisture.
 - Avoid dropping the product or treating it roughly.
 - Clean with a soft damp cloth.
 - DO NOT immerse the parent unit and the baby unit in water and do not clean them under running water.
 - DO NOT use cleaning spray or liquid cleaners.
 - Make sure the baby unit and parent unit are dry before you connect them to the mains again.

DISPOSAL OF BATTERIES AND PRODUCT

- The crossed-out wheelex bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.
- The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).
- The solid bar indicates that the product was placed on the market after 13th August, 2005. Help protect the environment by disposing of your product or batteries responsibly.

DECLARATION OF CONFORMITY

This product is intended for use within Europe and UK. This equipment complies with the essential requirements to EU's Radio Equipment Directive (2014/53/EU) and the UK's Radio Regulations 2017 on radio systems and telecommunication equipment.

VTech Telecommunications Ltd. hereby declares that this Audio Baby Monitor DM1212 is in compliance with the essential requirements and other relevant provisions of EU's Radio Equipment Directive (2014/53/EU) and UK's Radio Equipment Regulations 2017.

The Declaration of Conformity for the DM1212 is available from <http://www.vtech.com/rte-directive>.



Credits:

The *Background Noise* sound file was created by Caroline Ford, and is used under the Creative Commons license. The *Stream Noise* sound file was created by Caroline Ford, and is used under the Creative Commons license. The *Crickets At Night* sound file was created by Mike Koenig, and is used under the Creative Commons license. The *Heart Beat* sound file was created by Zarabadeu, and is used under the Creative Commons license.

STORAGE

When you are not going to use the baby monitor for some time, store the parent unit, the baby unit and the adaptors in a cool and dry place.

ADULT SUPERVISION

- This audio baby monitor should be for use by adults only.
- Do not place the baby unit inside the cot or playpen.
- To ensure your children's safety, do not allow them to touch or play with the baby monitor and its accessories. THIS IS NOT A TOY.