


INSTRUCTION MANUAL



Chuck SL

| | | |
|------------------------------------|---|--|
| <p>1.</p> <p>OFF</p> | <p>2.</p> <p>175mm 80mm</p> | |
| <p>3.</p> <p>INPUT: AC220-240V</p> | <p>4.</p> | <p>5.</p> <p>warning: when replacing a halogen lamp, wait for it to cool, for a minimum of 5 minutes</p> |
| <p>6.</p> <p>ON</p> | <p>Overall Sizes:</p> <p>inner small ring</p> <p>102 190 94 40°</p> | |