


2

### This accessory lets you use the Joy-Con™ controllers as a classic-style controller for the Nintendo Switch™ console.



Joy-Con controllers not included.  
Joy-Con Controller nicht enthalten.  
Joy-Con Controller nicht enthalten.  
Joy-Con-controllers niet inbegrepen.  
Joy-Con-controllers nicht inbegriffen.  
Joy-Con-controllers nicht inbegriffen.  
On console, Joy-Con also exists in individual.  
On console, Joy-Con non isolato.

#### Contents • Contenu



You can charge the controllers while you play by connecting the accessory to the Nintendo Switch console in TV mode using the USB charging cable. That way you don't need to worry about the batteries running out.

- **Modello stesso** Tabellone hanno di **Joy-Con Controller** in **Nintendo Switch** **Griffweise** mit der **Nintendo Switch-Konsole** **verwendbar**.  
• **Modèle du produit**, **Tableau de jeu** du **contrôleur** **utilisable**, **lorsque** la **console** **Nintendo Switch** **est** en **mode** **TV**.  
• **Questo accessorio** **può** **permettere** di **utilizzare** **gli** **accessori** **Joy-Con** **come** **una** **manopola** **classica** **per** **la** **console** **Nintendo Switch**.  
• **Vous** **pourrez** **recharger** **les** **manettes** **Joy-Con** **pendant** **que** **vous** **les** **utilisez** **en** **connectant** **cet** **accessoire** **à** **la** **console** **Nintendo Switch** **en** **mode** **TV**.  
• **Este** **accesorio** **permite** **usar** **los** **mandos** **Joy-Con** **como** **un** **mando** **clásico** **para** **la** **console** **Nintendo Switch**.  
• **Es** **posible** **recargar** **los** **mandos** **à** **la** **vez** **que** **se** **utilizan** **mediante** **el** **cable** **USB**.  
• **Ma** **de** **Joy-Con-controllers** **van** **resingeraald** **kan** **je** **de** **accessoire** **als** **een** **traditioneel** **controller** **voet** **het** **Nintendo Switch-systeem** **gebruiken**.  
• **Je** **kan** **de** **Joy-Con-controllers** **opladen** **terwijl** **je** **speelt** **door** **het** **accessoire** **aan** **de** **USB** **oplaadbare** **aan** **te** **sluiten** **op** **het** **Nintendo Switch-systeem** **in** **de** **TV** **modus**.  
• **Para** **cargar** **en** **comunidad** **durante** **un** **juego**,  **basta** **conectar** **el** **accesorio** **al** **cable** **de** **carga** **USB** **de** **la** **consola** **Nintendo Switch** **en** **modo** **teletv** **o** **utilizar** **el** **cable** **de** **carga** **USB**.  
• **Con** **questo** **accessorio** **puoi** **utilizzare** **i** **controller** **Joy-Con** **come** **un** **controller** **tradizionale** **per** **la** **console** **Nintendo Switch**.  
• **Puoi** **caricare** **i** **controller** **Joy-Con** **collegando** **l'accessorio** **alla** **console** **Nintendo Switch**, **quando** **gioca** **à** **in** **modalità** **TV**.  
• **Tramite** **il** **cavo** **di** **ricarica** **USB**, **in** **quarta** **modalità** **non** **devi** **preoccuparti** **che** **le** **batterie** **di** **scaricarsi**.

© Nintendo.  
Nintendo is a property of their respective owners. Nintendo Switch and Joy-Con are trademarks of Nintendo. Use marks appear with a hour preparation response.  
Nintendo Switch et Joy-Con sont les marques de Nintendo.  
www.nintendo.com  
EN, DE, FR, NL, RU, ES, PT, IT, TW, DA, PL, NO

MADE IN CHINA  
NAC-A-ESRBA(B)

0 454 961 83051  
1

UK CA  
EAC  
PAP  
RACCOLTA CARTA  
EUROPEAN UNION  
RECYCLED PAPER