

Lampen brechen oder beschädigt werden, darf die Kette nicht verwendet oder ans Stromnetz angeschlossen werden. Der Lichtschlauch darf nicht geöffnet oder abgeschnitten werden, um eine andere zu verbinden! Schließen Sie den Lichtschlauch nicht ans Stromnetz an, solange er in der Verpackung ist oder um eine Rolle gewickelt ist. Verwenden Sie die Kette nicht, wenn sie mit einem Gegenstand in Berührung ist, der die Oberfläche eingesunken ist. Bevor dem modellieren die Lichtschlange auf Zimmerentwurf einfach modelliert, geformt und gebeugt werden kann. Bitte beachten: Der mini-LED-Lichtschlauch kann beschädigt werden, wenn gebogen enger als ein 4cm Radius. Zur Befestigung verwenden Sie spezielle Befestigungsclips oder Kabelbinder benützen. Während Befestigung und Modellieren Netzstecker ziehen. Sorgen Sie immer dafür dass während brennen dieser Lichtschlange keine Wärme von diese Anweisungen befördert Sicherheit und Brennzeit Ihrer Lichtschlange.

g Instructions: The external flexible cable or cord of this luminaire cannot be replaced; if it shall be destroyed. The lightbulbs in this ropelights are non-replaceable. Where breakage of the chain must not be used / energised but disposed of safely. Do not open or cut the rope light connected to another. Do not connect the rope light to the supply while it is in the package. Do not use the chain when covered or recessed into a surface. Before modelling the ropelight it is to room-temperature after which the ropelight can be easily modelled, shaped and bent. The minimum bending radius is 4cm. The rope light can be damaged if bent tighter than a 4cm radius. Always use special mounting-clips or tie-raps. During attaching and modelling, always disconnect the power. Always ensure proper ventilation during use of this ropelight. Obeying these instructions will ensure your ropelight!



Transformator - Transformateur
Transformator - Transformer

IP44

Input: 100-240V-50-60Hz
Output: 36V +- 155mA - 4VA
C60 - PO.BOX 16
1738 ZG - WAARLAND (NL)

