












Quick start guide ^{A)}






*Tap water contains calcium which reduces the lifespan of the product C)



12

2 4 6



⋮ ⋮ ⋮

1x 2H timer ^{H)}

2 ● 4 ○ 6 ○

2x 4H timer ^{I)}

2 ○ 4 ● 6 ○

3x 6H timer ^{J)}

2 ○ 4 ○ 6 ●

4x 8H timer ^{K)}

2 ● 4 ○ 6 ●

5x 10H timer ^{L)}


2 ○ 4 ● 6 ●

6x continuous mode ^{M)}


2 ○ 4 ○ 6 ○

13


Auto off ^{N)}



14




1,5 sec




15

Off




1,5 sec




Optional ^{O)}

16 Filter ^{P)}



17 Aroma ^{Q)}

2 - 3



⚠ WARNING! Unplug 230V ! ^{S)}

