80X112mm

Wireless Earphone



CALL ANSWER

1) Android smart phone: the cap will be alarming with "DONG, DONG ... " while somebody calling. iPhone: the Headset will be alarming with phone calling music which is the same as the phone calling music in iPhone. 2) answer phone: press the power button one time to pick phone up.

3) Hang-up: Press the button again to hang-up. 4) Re-dial phone function: Press the button two times to redial the most recently phone number directly. 5) Phone number broadcasting: somebody call you, the device will sound broadcast the calling phone number, and the user will easy to know who calling.

Power save mode

The device will be off automatically after 5 minutes if no working device paired.

Low power warning

The device will be with the sound remind of "power low" while is working, it seems the power not enough, need to be charged.

Power Off

Press the button 3 seconds again, the device closed with the sound reminder of "power off", and the LED indicator off. • These instructions are for your safety. Please read through them thoroughly before use and retain for future reference.

PARTS INCLUDED

- Wireless Earphone
- Micro-USB to USB charge cable
- User manual

WARNING

- Waterproof grade of this product:IP67
- Please keep it out of small children reach, and stock against humidity and hot temperature.
- Please remove the electronic parts from the helmet when the device would be detached.
- Please keep the device against acidic, alkaline and cuspidal things.
- · Please do not disassemble, amend or alter device alone, and do not throw and drop it.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.

BATTERY WARNING

• Please make sure the charging time is about 2 hours at the first time.

- Do not throw the device in a fire, battery may explode or loak
- The Helmet with the electronic core shall not exposed to excessive heat such as burning sun, fire or the like,
- Do not replace the set-in rechargeable Li-ion battery alone.

FEATURES

- Wirelessly listen to music with integrated technology,.
- Fashion design, let music surrounding your life any time
- Hands free function, truly free your hand.
- Set-in rechargeable Li-ion battery, long stand-by and working time.
- Support power displaying on iPhone, easy to know when will to be charged.
- DIY design, available to be detachable when you want. Sound reminder function, easy to set the device according
- to sound remind.

SPECIFICATIONS

installation diagram

Fig.2

Move the clip and align

it on the left side of the

helmet Edge in.

- Frequency: 2.402GHz-2.480GHz
- Range: 10-15 meters (depending on device)
- Transmission distance of Microphone: ≦1 meter

• Li-ion battery: 3.7V/500mA

- Playback time: ≤ 15-20 hrs Charging Voltage: 5V
- Charging time: ≦3hrs
- Standby time: ≤240 hrs
- Connection name ·BT12

STRUCTURES

Fig. 1




Fig.4


Step 1

INSTALLING STEP

Take out the Wireless part from the color box, and find out the two earphone, put the earphone into the both sides of the ear position via magic tape (reference. Fig. 2)

Step 2

And then, put the suitable position, try to put the helmet on the head so that the device is on suitable position, you can modify the position by hand in order to well use it. (reference. Fig. 3)



Three times in a row can be automatically answer or not automatically answer the switch



Use a threading knife to loosen the threads. Easy to install.

Fig.3

2



Fig.5

Adhesion of Fur Magio to Helmets Left ear position.














Right horn

mic

Micro USB charge port

З

Peel off the white stripping paper of the wool magic sticker.

Stick the left horn to the magic The microphone is attached

CHARGING THE HEADSET Note: the Device will need to be fully charged prior to

initial use(approx, 2 hours). 1. Connect the micro-USB end of the charge cable to the

micro-USB port on the Cap(Fig. 1)

2. Connect the USB end of the charge cable to the USB port of the computer or adapter(not included).

3. The LED indicator (Fig. 1) will turn solid RED while charging and will turn off when fully charged.

Note: the Device can not be music playing or call answering while it is charging.



Fig.7 The right trumpet retreats like a demon Skilled white trip paper.

Fig.8

Stick the right horn to the magic Surgical past

Fig.9

he horn line is buried head is exposed. Charging and cocoa.

10

behind the helmet. In the interior, the rechargeable

DISPOSAL AND RECYCLING

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. Attention should be drawn to the environmental aspects of battery disposal.



9



to decrease the sound. Next song/increase the sound

Upper song/decrease the sound

USING THE HEADSET

reminder as"Power on".

of "power op" and the sound

of " BT12 " to pair,

2. Automatically repair

device open it again.

Broadcasting/Pause

the song

3. Automatically search

once the paired device is off.

Power On

Pairing

Press "+" one time for next song, continue press the button to increase the sound.

press"-" one time for upper song, continue press the button

Press the power button 3 seconds, the device will be sound

1. Press the BUTTON 3 seconds with the sound reminder

reminder of "pairing", then seek the Connection name

If your device is the latest recent paired device, the headset

will be automatically re-paired with your device when the

The device will be automatically into pairing mode again

Press button to pause the song, press it again to continue

Instalacion universal



Applicable to the following equipment:





