


akelen), 3. Druk de knop op de transformator kort in om de verlichting te dimmen (100% -
cordon de cet ensemble d'éclairage ne peut pas être remplacé ; si le cordon est endomma
icher l'alimentation lorsque la guirlande est toujours dans l'emballage. Les lampes ne peuver
tions : 1. "ON" pour allumé en continu, 2. "TIMER" pour allumé pendant 8 heures et éteint pe
du transformateur pour enclencher la minuterie), 3. Appuyer brièvement sur le bouton du tran
- 25% - OFF).

ing: Das flexible Kabel dieses Beleuchtungssets kann nicht ausgetauscht werden; wenn das Ki
gen. Die Kette nicht mit dem Stromnetz verbinden, so lange sie sich in der Verpackung befinde
Dieses Beleuchtungsset hat 3 Einstellungen: 1. „ON“ = Dauerbetrieb, 2. „TIMER“ = automatische
auf die Bedientaste am Transformator, um die Zeitschaltuhr für diese Leuchte zu aktivieren), 3. Dri
um das Licht zu dimmen (100% - 75% - 50% - 25% - OFF).

ctions: The external flexible cable or cord of this luminaire cannot be replaced; if the cord is dan
nnect the chain to the supply while it is in the packing. The lamps are not replaceable. This light se
on, 2. "TIMER" for switching the light on/off automatically (8 hours on and 16 hours off, to enable
nsformer for 3 seconds), 3. To dim the lights press the correct button on the transformer briefly (10



Transformator - Transformateur
Transformator - Transformateur
IP44

Input: 220-240V ~ 50-60 Hz.
Output: 3V \Rightarrow 300mA - 0,9VA
CBD - P.O.BOX 16
1738 ZG - WAARLAND (NL)