

AREBOS

Vacuum Cleaner 1800 W

AR-HE-IS18W



Please follow all security measures in this user's manual to ensure a secure use.



Thank you for trusting in AREBOS.

Content

1. Security instructions	3
1.1 Explanation of the symbols	3
1.2 General safety instructions.....	3
1.3 Special safety instructions	3
2. Assembly	4
3. Operation	4
4. Error detection.....	4
5. Technical data	5
6. Cleaning and maintenance	5
7. Environmentally friendly disposal	6
7.1 Disposal and packaging	6
7.2 Disposal of old equipment.....	6
EU Declaration of Conformity	7

Thank you for purchasing our product. Please read the operating instructions carefully before using the product for the first time. If you give the product to a third party, this manual must be handed over with it. Keep the instruction manual for future reference. The drawings in this manual may not match the physical objects. Please refer to the physical objects.

1. Security instructions

1.1 Explanation of the symbols



By means of a CE marking, it can be recognized that a product complies with the legal requirements of European legal standards and therefore may be traded within the European Community.



This product **must not** be disposed of with household waste!



This product has been tested and certified by Intertek. The symbol "GS" stands for tested safety. Products marked with are marked with this symbol, meet the requirements of of the German Product Safety Act (ProdSG).

1.2 General safety instructions

- If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The plug must be removed from the socket-outlet before cleaning or maintaining the appliance.

1.3 Special safety instructions

- Do not vacuum any sharp-edged, hot or incandescent materials.
- The appliance should not be exposed to heat.
- Unplug the appliance from the mains supply socket after use and before every cleaning. Pull the plug, not the mains cable, in order to disconnect the appliance from the mains.
- Do not put any object into openings. Do not use with any opening blocked. Keep free of dust, lint, hair etc.
- Do not use the vacuum cleaner without dust container or dust filter in place.
- Do not vacuum any flour, cement etc., in order to avoid the overloads.
- The appliance should only be cleaned with a dry or damp cloth; it should never be immersed in water. Do not use any solvents for cleaning.

- This appliance is intended for domestic use only and not for commercial applications.
- Avoid the nozzle or brush touching the surface of the furniture.
- Do not use the mains wire to carry the appliance. Do not pull the mains wire over sharp edges.

2. Assembly

- Insert four wheels into the wheel base.
- Put the sponge in the dust container carefully.
- Put the hepa filter in the dust container carefully.
- Put the non-woven bag filter in the dust container carefully.
- Attach the dust container to the hand vacuum cleaner. And pull tight of the hook.
- To use the flexible hose, insert the end of the hose into the suction hole. Make sure, that it is snapped in the position.
- Choose your desired accessory (brush or nozzle) and attach it to the suction hole.

3. Operation

- Before you start the appliance, make sure that the hepa filter is in the position.
- Before you start the appliance, make sure that the hose assembly is in the position or else the appliance had mangled.
- Insert inside to start blowing function.
- Unwind the power cord.
- Plug the appliance and switch on.
- Unplug the appliance after use.
- Attach the desired accessories to the vacuum cleaner.

4. Error detection

Before you contact our service centre, please check the following:

Problem	Possible reason	Advice
Motor does not start	<ul style="list-style-type: none"> - Power cord not firmly plugged into outlet. - Outlet damaged. - Cleaner not switched on. 	<ul style="list-style-type: none"> - Plug unit firmly. - Check the Outlet. - Switch on the appliance.
Suction power is weaker	<ul style="list-style-type: none"> - Unit clogged. - Paper filter needs replace. - The Water drain plug is opened. 	<ul style="list-style-type: none"> - Remove the blockage. - Replace the paper filter. - Close the Water drain plug.

5. Technical data

Material	Polypropylene / stainless steel
Hose length	3 m
Cable length	4 m
Suction power	33 L / sec
Volume	30 L
Suction force	≥18 kPa
Filters	replacable
IP Classification	IP24
Measurements of the product? (cm)	36.3 x 36.3 x 62 cm (with rollers)
Weight of the product	6.2 kg
Voltage	220-240 V, 50/60Hz
Power	1800 W
Protection Class	II

6. Cleaning and maintenance

- Turn the waterproof seal cover and fix well after water drain out.
- Open the dust container.
- Take out the hepa filter.
- Take out the non-woven bag filter.
- Fall the rubbish into dustbin.
- In necessity, wash off the dust filter with cleaning water.
- Dry up the dust filter.
Attention: Do not put in the sun.
- Wash off the non-woven bag filter with cleaning water.
- Dry up the non-woven bag filter.
Attention: Do not put in the sun.
- Assemble the vacuum cleaner.

7. Environmentally friendly disposal

Warning Danger of suffocation! Packaging material is dangerous for children. Never let children play with packaging material.

7.1 Disposal and packaging

- The packaging of your unit consists of materials that are necessary to guarantee effective protection during transport. These materials are fully recyclable and therefore reduce the environmental impact. Dispose of the packaging in a bin for recyclable materials.

7.2 Disposal of old equipment

- Old appliances must be disposed of in accordance with the guidelines and regulations of the local waste disposal authority. Check with your local administration for the address of the nearest recycling centre and deliver your appliance there.



The symbol of the crossed-out dustbin on a Waste electrical or electronic equipment indicates that it must not be disposed of with household waste at the end of its life. Collection points for waste electrical and electronic equipment are available free of charge in your area. You can obtain the addresses from your city or local government. You can find out about other return options created by us on our website www.arebos.de.



The separate collection of Waste electrical or electronic equipment is intended to enable the reuse, recycling or other forms of recovery of Waste electrical or electronic equipment and to avoid the negative consequences of disposal on the environment and human health.

Our customer service number: Tel. +44 (0) 208 068 5604

Fax: +49 (0) 931 4523 2799 / E-Mail: info@arebos.de

Office address: Canbolat Vertriebs GmbH • Gneisenaustraße 10-11 • 97074 Würzburg

Return address can be found in the imprint: <https://www.arebos.de/impressum/>

EU Declaration of Conformity

We, the

Canbolat Vertriebs GmbH, Gneisenaustraße 10-11, 97074 Würzburg, Germany,

hereby declare that the equipment described below, by virtue of its design and construction and in the versions placed on the market by us, complies with the relevant essential health and safety requirements of the EU directives.

Product name: AREBOS Vacuum Cleaner 1800 W

Model number: AR-HE-IS18W

Article number: 4260627420117

Should the appliance be modified without our consent, this declaration of conformity will lose its validity.

Tested according to:

EU standard:

EN 60335-2-2:2010+A11:2012+A1:2013

EN 60335-1:2012+AC:14+A11:14+A13:2017+A1:2019+A2:2019+A14:2019

EN 62233:2008

EN 55014-1:2017+A11:2020

EN 55014-2:2015

EN IEC 61000-3-2:2019

EN 61000-3-3:2013+A1:2019

AfPS GS 2019:01 PAK

Date/Signature Manufacturer/Place:

Würzburg, April 11, 2022



Signature:

Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

Representative of these instructions for use/technical data:

Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

Office address:

Canbolat Vertriebs GmbH

Gneisenaustraße 10-11

D-97074 Würzburg

Return address can be found in the imprint: <https://www.arebos.de/impressum/>

VAT identification number: DE 263752326

Court of the Commercial Register is Würzburg, HRB 10082

WEEE Reg.-No. DE 61617071