

WARNINGS

- Use this product under supervision of an adult.
- This product must be assembled by an adult.
- Do not expose this product to excessive heat sources. Keep away from fire.
- Use a soft damp cloth to wipe off this product, and dry off using a clean dry rag. Never use harsh cleaning agents.
- Do not use in traffic. Protective equipment should be worn (e.g. helmet, kneepad, etc.)
- This item requires a specific skill to use. In case of unskilled user, overturning and collisions are possible.
- WARNING Keep plastic parts away from children to prevent suffocation
- Ensure that moving parts, joints, etc. of this item are inspected by an adult on a regular basis. Children should be instructed not to act otherwise.
- PILSAN reserves the right to change and amend the specification of this product at any time without notice. The product may vary in colour than the images. Accessories are not included. Please always use PILSAN original parts.
- The product shouldn't be used in risk areas such as slopes, next to pools, bumps with grooves, etc.
- The product is designed for the use of one child and two children cannot use it at the same time.
- The pen inside the package is suitable for child's use. If it is exhausted, please purchase a new one.
- Do not leave your child alone.



EN 71-1
EN 71-2
EN 71-3



[Small, mostly illegible text and symbols at the bottom of the page, including a red prohibition sign with '0-3' inside.]