

Angel Juicer
SINCE 1982

Product Name: Electric Juice Extractor

Model No: **ANGELIA 7500**

Voltage: 220V ~ 240V

Frequency: 50Hz, 180W

Proper Electricity Consumed:

S/N: [REDACTED]



Made in Korea

General Safety Instructions

1. To protect against electric shock, do not immerse cord, plug or water or any other liquid.
2. Careful supervision is necessary when this appliance is used. Do not let the children use the appliance.
3. Always use the food pusher provided with the appliance to push food or vegetables into the feeding chute.
4. Unplug power cord from the outlet when the juicer is not in use.
5. Do not run the appliance when run without the food pusher.
6. Do not force too much fruits and/or vegetables into the feeding chute.
7. Do not hang the electrical cord over the edge of a counter, in a drawer or on a burner or other heat source.
8. Recommended circumstance temperature: 10°C to 35°C.
9. The appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, unless they have been given proper instruction and supervised to ensure safe use.